



290i & 290s

Multi-Function Indicator

Weighing Scales Series

Operation Manual (Full Version)



PLEASE READ THIS MANUAL VERY CAREFULLY
BEFORE OPERATING THIS INSTRUMENT

Specifications subject to change without prior notice

Contents

1. Reminders	8
1.1 Metrological Legislation	8
1.2 Seal & Serial Number	8
1.3 Warm-Up Time	8
1.4 Placing this instrument.....	8
1.5 Cautions.....	8
1.6 Support & Service	8
2. Specifications	9
3. Panel & Keys.....	10
3.1 Keyboard Description	10
3.2 Display Panel Description.....	11
4. Connection Points	11
4.1 Connection Pins & Plugs	11
4.2 RS232 Comports Pin Assignment for UART 0 & UART 1	12
4.3 Load cell connector pin assignment	12
5. Power Adaptor, Built-In Batteries & Recharging	12
5.1 Power Adaptor	12
5.2 Before Plugging in Power Adaptor to Electricity Grid	12
5.3 Before First Time Use	12
5.4 CR1220 Real-Time Clock Backup Battery.....	13
5.5 Battery Voltage & Battery-Operation Application	13
5.6 Battery Low	13
6. Internal Function Settings	13
6.1 About Internal Function Table	13
6.2 How to Enter & Select Internal Function.....	13
6.3 Key Function during Internal Function Setting & Operation Mode	13
6.4 Internal Function Table.....	14
7. Recommended Setting Procedures for User	21
8. UART & Comport Settings	21
8.1 UART Description	21
8.2 Parameters Table for PC/Command/serial Scanner.....	22
8.3 Parameters Table for Auto 1 ~ 3 & Manual	22
8.4 Heartbeat Connection Check Function for WIFI	23
8.5 When Bluetooth is selected	23
9. Basic Operation.....	24
9.1 Power Instrument On & Off.....	24
9.2 Power on Countdown Process	24
9.3 Operator Number	24
9.4 Warm-Up Time	24

9.5 Keyboard Lock	24
9.6 Loading & Weighing	24
9.7 Manual Zero	24
9.8 Tare Functions	24
9.8.1 Manual & automatic tare	24
9.8.2 Repetitive/multiple tare	24
9.8.3 Preset tare	25
9.9 Select the Preferred Weight Unit	25
9.10 Select the Preferred Function Mode	25
9.11 Check Functions	25
9.11.1 Input check limits manually	26
9.11.2 Cancel check limits inputted	26
9.11.3 Hints for entering Lo & Hi Limits	26
9.12 Tri-color Backlight	26
9.13 Auto Power Saving & Auto Power-off Time.....	26
9.14 Extended Display Mode	26
10. Memory & Data Related Operation	26
10.1 Memory Accumulation	26
10.1.1 Automatic accumulation	26
10.1.2 Manual accumulation	26
10.1.3 When data is accumulated to memory	27
10.1.4 Memory recall & clearance	27
10.2 Expiry Date	27
10.3 Machine ID, Group & Operator Numbers	27
10.4 Inputting Numbers, Letters, Symbols via Keyboard	27
10.5 Customer/Product Code & Description	27
10.5.1 Entering customer/product code & description manually	28
11. Weighing Mode.....	28
12. Animal Weighing Mode	28
12.1 Description of Animal Weighing Mode	28
12.2 Animal Weighing Mode Settings	28
12.3 Start Using Animal Weighing	29
13. Near Zero Function Description	29
14. Barcode Scanner	29
14.1 Barcode Scanner Setup.....	29
14.1.1 Serial barcode scanner setup	29
14.1.2 CT10 serial barcode scanner setup.....	29
14.2 Barcode Scanner Functions	30
14.2.1 Simulating operation key	30
14.2.2 Entering Customer/Product Code & Operator Number	30

14.3 Embedding Input Target Information into a Barcode/RFID Tag	30
14.4 Barcode Scanner & Auto Database Search	31
15. Label Printing	31
15.1 Label Format Groups & Label File Names	31
15.1.1 FL1 (Label Format Group 1)	31
15.1.2 FL2 (Label Format Group 2)	32
15.2 Repetitive Printout.....	32
16. Alibi Transaction Memory & Management Report	32
16.1 Alibi Memory Description	32
16.2 Define when a Transaction Data is saved to Alibi memory	33
16.3 Adding Short Note to Alibi Management Report	33
16.4 Checksum	33
16.5 Output & Settings for Alibi Memory & Management Report	33
16.6 Totalization	34
17. Data Output Protocols & Formats	34
17.1 PC Output Protocols	34
17.2 Data & Print Formats	34
17.2.1 Predefined output formats	34
17.2.2 Lab 2 customized output format	34
18. Production Settings PLU	34
18.1 Create & Save Production Settings PLU	34
18.2 Recall a Production Settings PLU.....	34
18.2.1 Keyboard method	35
18.2.2 Barcode scanner method.....	35
18.2.3 Computer command method	35
18.3 New Code Scanned/Inputted when a Production Settings PLU is Running.....	35
18.3.1 In case new customer/product code is by barcode scanner	35
18.3.2 In case new code/description is inputted by keyboard	35
18.4 To quit from the Current Production Settings PLU.....	35
18.4.1 Keyboard Method	35
18.4.2 Scanner method.....	35
19. Commands	36
20. Built-in Battery & Recharging	36
20.1 Battery Operation Time	36
20.2 Symbols & Remaining Power	36
20.3 Battery Recharge	36
21. System & Error Codes	37
22. Daily Care & Maintenance	38
Appendix A: - Pre-Defined PC Output Protocols.....	38
A.1 Data Abbreviation Table.....	38

A.2 Output Formats Tables	39
Appendix B: - Customized PC Output Protocol	41
B.1 Customized PC Output Protocol Setting Procedures.....	41
B.2 Customized PC Output Content Table	42
Appendix C: - Lab 1 Output Formats	44
C.1 Weighing & Animal Mode Predefined Output Format Illustration.....	44
C.2 Customized Lab 1 Output	44
C.2.1 Customized Lab 1 Output Setting Procedures.....	44
Appendix D: - Lab 2 Standard Output Format	45
D.1 Weighing Mode Illustration	45
D.2 Animal Weighing Mode Illustration	45
Appendix E: - Customizing Lab 2 Print Format.....	46
E.1 Print Output Format Variants Table	46
E.2 To Edit Custom Lab 2 Print Output Format	47
Appendix F: - Lab 3 Output Format	48
Appendix G: - Lab 4 Output Format.....	49
Appendix H: - Lab 5 Output Format	50
Appendix I: - TSC Printer Installation, Setup & Label Upload Procedures	51
I.1 Get the below ready before Printer Installation	51
I.2 Printer Installation	51
I.3 Uploading TCF File to Printer	51
I.4 Create & Upload Label to TSC Printer.....	52
I.4.1 Selecting the Correct Edition for Bartender Software	52
I.4.2 Adding Information from Instrument to Label & Uploading to a TSC Printer	52
Appendix J: - Sbarco Printer Installation, Setup & Label Upload Procedures	54
J.1 Get the below ready before Printer Installation.....	54
J.2 BarDrawer Software & Printer Driver Installation.....	54
J.3 Create & Upload Label to Sbarco Printer	54
Appendix K: - Label Programming, Illustration & Samples	56
K.1 Label Prompt Command Table	56
K.2 Label programming Illustration	58
K.2.1 Label Illustration for LP50 & TSC	58
K.2.2 Label Illustration for Sbarco.....	58
K.3 Sample Labels	58
Appendix L: - Keyboard Commands	59
Appendix M: - System Execution Commands.....	60
Appendix N.1: - Management Report Execution Commands	61
Appendix N.2: - Relationship between ABSN (Alibi Memory Address Number) and ABNR (Alibi Record Number)	62
N.2.1 About Alibi Memory Address Number (ABSN)	62
N.2.2 About Alibi Record Number (ABNR).....	62

N.2.3 Cycle Relationship:	62
N.2.4 Example Scenario	62
Appendix O: - System Parameter & Operation Entry Setting Commands	63
Appendix P.1: - System Parameter & Operation Entry Reading Commands	65
Appendix P.2: - Parameter Reading Commands of Production Settings PLU in effect	68
Appendix Q: - Operation Result Reading Commands	69
Appendix R: - Production Settings PLU Saving Commands	71
R.1 Command Description Table	71
R.2 Parameter Description Table	71
Appendix S: Production Settings PLU Reading Commands	73
S.1 Command Description Table	73
S.2 Parameter Output Description Table	73
Appendix T: Production Settings PLU Execution Commands.....	75

1. Reminders

1.1 Metrological Legislation

Local metrological legislation may limit access to some settings of this instrument. Do not attempt to change any parameters under internal function number F39 ~ F99. Contact your dealer for installation and technical assistance.

1.2 Seal & Serial Number

This instrument is legal for trade only when sealed and bearing a serial number. Do not attempt to break the seal or serial number affixed to this instrument. Warranty service voided if the seal or data plate of this instrument is damaged or removed. Always contact your dealer for after-sales service.

1.3 Warm-Up Time

- a. Allow a warm-up period of not less than 60 seconds before calibration and usage. The higher the resolution of the setting, the longer the warm-up period is required.
- b. In most cases, 120 seconds is a safe warm-up period for all applications. This warm-up period is needed to energize all components to reach a stable status.
- c. The internal count value is stable when the internal AD count varies by less than 3 counts within 2 seconds.
- d. To read the internal AD count value, enter internal function F1. The internal AD count value may go up continuously when instrument is not yet fully warmed up.

1.4 Placing this instrument

Always place the weighing platform on a solid and level surface. Avoid using the scale in any environment where excessive wind flow, vibration, and extreme temperature changes exist. Contact your dealer if in doubt.

1.5 Cautions

- a. This instrument is not an explosion-proof device.
- b. This instrument is not a waterproof device.
- c. Do not open this instrument, no user-serviceable parts inside. Always contact your dealer for service.
- d. Do not place this instrument in where shock, excessive vibration, or extremes of temperature (before or after installation) exist.


1.6 Support & Service

Always contact your dealer for product information, after-sales service, and questions when in doubt.

2. Specifications

Capacity and Readability	Free Setting
Weighing Range	Single Range, Dual Range, Dual Interval
Weight Units	kg, g, lb
Display	6 x 45mm Huge Size Bold Type Wide Angle LCD Numeric Digits
Load Cell Connection	- Excitation Voltage = 5V DC - Support both 4-wire & 6-wire Load Cells - Maximum Load Cell Connection: 4 x 350Ω or 8 x 700Ω Load Cells
A/D Converter & Internal Resolution	24 bit Low-Noise Sigma to Delta 4,000,000 Counts at 20 mV - Minimum input per d = 0.05μV
AD Conversion Speed	15, 30, 60, 120 times/second Selectable
Max. Tare Range	-Max for Single Weighing Interval or -Max1 (Subtractive Tare)
Calibration Methods	2 Span Points Calibration (Linearity Calibration), or 1 Span Point Calibration, or - Numeric Calibration Through Keyboard
Power Source	- Built-in Rechargeable Battery = 6V, 4AH - External Power Adaptor = DC 12V, 1A
Accessories	- Dust Cover - Pillar Mount Holder (φ35 ~ 38mm) - Built-in Rechargeable Battery - Universal Power Adaptor
Packing	- Individually Packed. 36 x 33 x 16cm. Net/Gross = 2.50/2.90kg - Four Units in a Shipping Carton. 68 x 38 x 36cm. Net/Gross = 10.00/13.50kg
Operation Environment	- Temperature: -10°C to 40°C - Humidity: ≤85%, Non-condensing
<i>In the interest of improvement, specifications may change without prior notice</i>	

3. Panel & Keys



3.1 Keyboard Description

No.	Description	Function Description	
		Normal Operation	Internal Function Setting
1	[On/Off]	Power the instrument on or off.	Quit without saving and power off.
2	[Zero]	Set weight displayed to zero when unloaded.	Quit without saving.
3	[Tare]	Tare off the weight of a container.	- Set F1 value shown to zero and display the net span gain of the additional load applied. - Access internal functions F1–F99 during power-on countdown.
4	[Func]	Switch between weighing, animal weighing, and other auxiliary functions. ¹	- Move to the next parameter or internal function number. - Move cursor one place to the right.
5	[Unit] ²	Switch among various weight units (if unit conversion is enabled).	- Move to the previous parameter or internal function number. - Move cursor one place to the left.
6	[Set]	- In weighing mode: access internal function setting mode (F1–F37). - In animal weighing mode: prompt or enter an operation parameter/value.	- Enter internal function numbers F1–F37 during weighing mode. - Enter, save, and return.
7	[PT]	Start entering a preset tare value.	NIL.
8	[Print/M+]	- When loaded: Send print data and/or accumulate the current value to accumulation memory. - When unloaded: Accumulation memory recall (MR).	- Increase numeric value by 1. - Quick access to the higher 10th internal function available.
9	[Check/PLU]	- Short press: start entering Lo and Hi weight limits. - Long press: recall a production setting PLU.	- Decrease numeric value by 1. - Quick access to the lower 10th internal function available.

¹ Depends on F11 setting.



² Refer to F9 on how to enable/disable weight units.

10	[CE/x10]	- Short press: Clear an entered value during the setting process - Long press: Trigger extended display mode.	Clear.
----	----------	--	--------

3.2 Display Panel Description

No.	Name	Description
12	Max₁ Indicator	(When under dual weighing range/interval mode) Visible when instrument is operating at the first weighing range (W ₁).
13	Max₂ Indicator	(When under dual weighing range/interval mode) Visible when instrument is operating in the second weighing range (W ₂).
14	Minus Indicator	Visible when a negative value is being displayed.
15	Gross Indicator	Visible when the gross result is being displayed.
16	Net Indicator	Visible when the net result is being displayed.
17	Stable Indicator	Visible when weight detected is stable.
18	Zero Indicator	Visible when instrument is at zero weight status.
19	M+ Indicator	Visible when memory contains accumulated data.
20	Data Indicator	- Visible when a preset-tare value or a Production Settings PLU is in effect. - Flash when transaction record is sent to Alibi memory (Alibi memory).
21	Weight Unit Indicator	kg = kilogram; g = gram lb = pound.
22	Reserved	
23	Reserved	
24	Battery Level Indicator	Visible to show remaining battery of the built-in rechargeable battery.
25	Numeric & Alphabetical Info Panel	Numeric value and alphabetical Info are displayed here.

4. Connection Points



4.1 Connection Pins & Plugs

A. DC Jack Input for Indicator

External power adaptor (DC9 ~ 12V) is plugged in here. Do not plug in any other power adaptor than the one which comes with this instrument.

B. Reserved

C. Load Cell Connector (7-Pin)

- 290i: - Signal wires from load cell (or junction box) are connected here.
- 290s: - Thread through signal cable from load cell (or junction box) here.

D. Control Output Port

- 290i: - Optional Control output port.
- 290s: - Thread through optional control output cable here.

E. UART 1 Port

- 290i: - UART 1 serial port is connected here.
- 290s: - Thread through cable of UART 0 here.

F. UART 0 Port

- 290i: - UART 0 serial port is connected here.
- 290s: - Thread through cable of UART 1 here.

G. Reserved

4.2 RS232 Comports Pin Assignment for UART 0 & UART 1

Comport 0 (UART 0, Male)	Comport 1 (UART 1, Female)
2 = RXD	2 = TXD
3 = TXD	3 = RXD
5 = GND	5 = GND
9 = DC 5V Output	Nil

4.3 Load cell connector pin assignment

Pin # on Load Cell Connector	Pin Assignment
1	Excitation +ve
2	Remote Sense +ve
3	Excitation -ve
4	Remote Sense -ve
5	Signal +ve
6	Signal -ve
7	Ground

5. Power Adaptor, Built-In Batteries & Recharging

5.1 Power Adaptor

Always use the power adaptor supplied with this instrument to avoid unrecoverable damage.

5.2 Before Plugging in Power Adaptor to Electricity Grid

Check if the input voltage marked on the power adaptor matches with the local electricity grid. If not, do not plug in and contact your dealer immediately.

5.3 Before First Time Use

To ensure the best battery performance, recharge the built-in battery for at least 8 hours before first-time use.

5.4 CR1220 Real-Time Clock Backup Battery

A CR1220 battery is installed to back up the system real-time clock and other application parameters. Replace this battery with a new one every 12 months for best performance. Contact your dealer for more information and support.

5.5 Battery Voltage & Battery-Operation Application

Battery voltage is displayed by Battery Level Indicator and by internal function F2.

When the battery voltage level drops below 6.0, battery operation time may be less than 60 minutes (depends on actual system configuration).

5.6 Battery Low

- When **Lo Bat** message appears during power on counting process; it means battery level is at extremely low level. Recharge battery immediately.
- During operation status, this instrument will power off automatically when the battery level is extremely low. If this is the case, do not attempt to power on this instrument. Recharge this instrument immediately. Failure to do so may cause unrecoverable damage to the built-in rechargeable battery.

6. Internal Function Settings

6.1 About Internal Function Table

To enable this instrument to give the best performance under various application requirements and demands, a set of internal functions is built-in.

These internal functions are divided into 2 categories: -

- User accessible functions (F1 ~ F37 of below table) do not require any password to access.
- Other internal functions are not for access to end-users and may need a password to access. Do not attempt to access or alter any parameters without authorization to avoid system malfunction.

6.2 How to Enter & Select Internal Function³

1. In weighing mode, press and hold [Set].
2. Instrument displays F1 and is now in internal function mode.
3. Press **[Func]** or **[Unit]** to select the preferred internal function number and press **[Set]** to enter.
4. Quick access to a function number: -
 - a. Press **[Print/M+]** to access to the higher 10th internal function.
 - b. **[Check/PLU]** to access to the lower 10th internal function.

6.3 Key Function during Internal Function Setting & Operation Mode

Refer to **paragraph 3.1** for more information.

³ To fulfil the metrology law of certain countries, accessing to internal function by **[Set]** key may be disabled. Contact your dealer for more information.

6.4 Internal Function Table

Function No.	Description	Parameters / Note Default = **						
F1	Internal Analogue to Digital (ad) Value	Press [Tare] to set offset value to zero when unloaded. Then add load on the platform to observe the span value of load applied. - When ADC is more than 1 million. W₁ sign will appear. Actual ADC is = 1 million plus the ADC value being displayed. - When ADC is more than 2 million. W₂ sign will appear. Actual ADC is = 2 million plus the ADC value being displayed. - When ADC is more than 3 million. Both W₁ & W₂ sign will appear. Actual ADC is = 3 million plus the ADC value being displayed. Press [Zero] to quit to F1.						
F2	All Segment Check	All display segments and backlight colors will be lit on. Check any segments or backlight colors are missing.						
F3	Capacity, Division & Default Weight Unit	Display basic metrology characteristics (capacity, division and weight unit). Value displayed = Max + 1e						
F4	Date Format & Date	DD/MM/YY	** YY/MM/DD			MM/DD/YY		
	1. Press [Func] or [Unit] to change date format and press [Set] to confirm. 2. Press [Set] to check the current date value. 3. To adjust date value, input date value and press [Set] to confirm. 4. Instrument will then display the date value inputted into week and day number (0 ~ 6 for Sunday ~ Saturday) of the year value inputted. 5. Select Date Output Type: - 2 parameters are available: - ➤ Date = Normal date format as per input above. ➤ Week = WWYYDD format. WW = week number; YY = year value; DD = weekday (Monday = 01... Sunday = 07).							
F5	Time	HH/MM/SS						
	To change time, press [Set] , then enter a new value and press [Set] .							
F6	System Initialization (Set F7~F37 to Default)	** NO			YES			
	If YES is selected, press [CE/x10] when “ SURE ? ” is displayed. Indicator shows Done when initialization is completed.							
F7	Auto Power Off Time (Minute)	OFF	1	3	** 5	10	20	Other
	Auto power off function will be disabled when an energized power adaptor is plugged in.							
F8	Backlight Brightness & Color Ratio	Brightness (01 ~ 99) ** Default = 60			Color Ratio (Green Vs Red) ** Default = 40			

	- To change the brightness, enter the preferred brightness value and press [Set]. Then enter the preferred color ratio and press [Set] to save. - Color (Col) ratio is used to generate the preferred yellow color. When instrument is powered by built-in rechargeable battery, backlight will be turned to minimum when battery is low or when weight value remains unchanged for 5 seconds.									
F9	Weight Unit Enable / Disable	kg (** On/Off)			g (On/** Off)			lb (On/** Off)		
F10	Filter Strength	1	2	3	4	** 5	6	7	8	9
	Notes: - - Set Filter Strength first, then followed by Anti-Vibration Level, and then AD Conversion Speed. 9 filter strength parameters (1 ~ 9) are available: - 1 (strongest filter) for bad working environment where vibration, wind flow etc. affect stable reading, 5 for normal environment, 9 (least filter) for good working environment where wind and vibration do not affect the stable reading. 5 Anti-vibration levels (1 ~ 5) are available. The higher the Anti-Vibration level set, the longer the time needed before a stable result is obtained. 1 (least) for good working environment where vibration does not exist. 5 (strongest) for bad working environment where serious vibration exists and stable readings are not easy to obtain. 4 AD conversion speed parameters (15 ~ 120 time per second) are available: - 15 times per second (slow speed). Good for high-resolution applications. 30 times per second (medium speed). Recommended maximum resolution = 15,000 division 60 times per second (high speed). Recommended maximum resolution = 7,500 division 120 times per second (ultra-high speed). Recommended maximum resolution = 3,000 division To set filter strength and AD conversion speed: - - Press [Set] to enter, then: - - Press [Func] or [Unit] to select the preferred filter strength, then [Set] to confirm, or - Press [Zero] to quit. - Instrument displays the AD conversion speed setting page. At this point: - - Press [Func] or [Unit] to select the preferred AD conversion speed, then [Set] to confirm, or - Press [Zero] to quit. If any parameter is changed, instrument will restart automatically.									
F11	Auxiliary Function	- Ani (Animal Weighing mode)/On/** Off - PCd (Quick Access to Customer/Product Code Setting)/On/** Off - oP (Operator No) /On/** Off - Not (Transaction Note to Alibi Memory) On/** Off								
F12	Auto Tare Function	** OFF			ON			Contin		
	Notes: - Off = Auto Tare Function disabled. On = Only the first stable weight applied will be tared off. Minimum tare load ≥ 2d. Contin = All stable weight applied will be tared off after the selected delay time. Minimum tare load ≥ 10d.									

	○ If Contin is set, select also delay time (0.0 ~ 9.9 second). Delay time is the duration from a stable weight is detected until it is automatically tare off. ○ Delay time is displayed. Input the preferred delay time and press [Set] to save.					
F13	Repetitive Tare Function	Off		** On		
	If F12 is set = Contin , Repetitive Tare setting “Off” will be surpassed.					
F14	Buzzer	Kb (keypad buzzer) (**On /Off)		St (System buzzer) (**On /Off)		Alibi Memory (**On /Off)
	To enable and disable a specific function buzzer: - 1. Press [Func] or [Unit] until the preferred parameter is displayed. 2. Press [Set] to save and go to the next function buzzer. 3. Repeat the above procedures until instrument returns to F14.					
F15	Check Result Buzzer	Off	** In	Out	Hi	Lo
	• Off = Check Buzzer disabled. • In = Check Buzzer activates when reading is within range. • Out = Check Buzzer activates when reading is out of range. • Hi = Check Buzzer activates when reading more than Hi limit. • Lo = Check Buzzer activates when reading lower than Lo limit. Setting procedures: - 1. Press [Func] or [Unit] to select the preferred parameter. 2. Then [Set] to save and continue with Action on Negative Value setting. 2 parameters are available: - • nE On = Check function applies also to negative results. • nE Off = Check function does not apply to negative results. 3. Then [Set] to save and return to F15.					
F16	Communication Ports Setting	UART 0	UART 1	BT	WIFI	USB
	Refer to paragraph 8 for more setting details.					
F18	Machine ID and Group Number	Machine ID (00~99)			Group Number (00~99)	
	Notes: - • Group number can be used as production line number in a multi-instrument application. • The machine ID and group number inputted will be carried out on printout formats Lab 3 ~ Lab 5. Setting procedures: - 1. Go to F18 and press [Set]. 2. Input Machine ID number (00 ~ 99) and press [Set]. To clear machine ID number, press [CE/x10] and press [Set] to save.					

	3. Then Input group number (00 ~ 99) and press [Set] . To clear the group number, press [CE/x10] and press [Set] to save and return to F18.		
F19	Manual Entry for Customer/Product Code & Description	P Code (Product Code & Description)	C Code (Customer Code & Description)
	- Customer & Product code accept both numeric numbers and alphabets. Maximum length = 18 digits (; * # not accepted). - Customer & Product Description accept both numeric numbers and alphabets. Maximum length = 30 digits (; * # not accepted). - Keyboard on instrument allows only numeric numbers. To enter letters and symbols, use barcode scanner, smart devices or computer. Notes: - a. If a Product/Customer Code is = blank, Product/Customer Description will be ignored. b. Customer and Product code does not support print format 1 (Lab 1). c. Customer and product code inputted will be sent to output formats Lab 2 ~ Lab 5.		
F20	Keyboard Lock	** Off (Disable)	On (Enable)
	When keyboard lock is = On , only [Set] , [Zero] , [Tare] and [On/Off] key will be accessible during operation status.		
F21	Weight Function Lab 2 Print Format	** Std	Custom
F24	Animal Functions Lab 2 Print Format	** Std	Custom
F25	Check Modes	Mode 0	** Mode 1
	- Mode 0 = Static Check Mode (only stable weight results are checked). If selected, input also the delay time interval. - Delay time interval is the time value (in second) from when a stable result is detected, and before the corresponding check result signal/output is triggered. - Mode 1 = Standard/Dynamic Check Mode (real-time check result is given disregarding weight results are stable or not). If Mode 1 is used for dynamic application, set also F26. Note: - if Mode 1 is selected, set also F26.		
F26	Near Zero Weight Value	** 000000	
	Near Zero value is used for dynamic weight check applications to bypass unnecessary Lo signals during uploading and unloading process.		
	Notes: - - Value inputted valid only when Check function is activated. - No check results will be given to weight results which is less than the near zero value. - Near zero weight value can be any value between 20d and Lo limit.		
F27	Decimal Point Format	** Dot (.)	Comma (,)
F28	Ask for Operator Number when Power on	Yes	** No
	- Yes: - Instrument will ask for operator number during countdown process when power on. Enter 4-digit operator number or press [CE/x10] to skip operator number when being asked. - No: - Instrument will not ask for operation number when power on.		

F29	Read Calibration and parameter set counts. • O (Parameter set count): - shows total times that the important parameters (F80~F88) has been altered. • C (Calibration count): - shows total times of calibration.	
F33	Report Output Comport & Content Settings	Set report output comport No. and report content setting
	Setting procedures: - 1. Press [Set]. 2. Name of the report output communication port is displayed. 3. Press [Func] or [Unit] until the preferred report output UART number appears and press [Set]. 4. Instrument displays report detail setting. 2 parameters are available: - a. All = All report detail will also be outputted. If All is selected, instrument returns to F33. b. Custom = To customize which of the below-mentioned optional report detail will be outputted. Report detail & Parameters: - • oP. Code = Operator No. • oP. Mode = Operation Mode No. • id = Machine ID. • Group = Machine Group No. • Time = Time of the individual transaction • C Code = Customer Code. • C_dESC = Customer Description. • P Code = Product Code. • P_dESC = Product Description. • Ref = Lo and Hi limit value of the individual transaction. • Result = Check result of the individual. • Note = Note • Title = Report Title • Header = Report Header • Footer = Report Footer • CHKS = Checksum 5. If Custom is selected, follow the below procedures for report detail settings. a. Instrument displays the report detail and parameter. b. Press [Func] or [Unit] until the preferred parameter (On = enabled; Off – Disabled) and press [Set] to save and go to the next report detail and parameter c. Repeat the above steps a and b to set all other report detail until instrument returns to F33. d. At this point, the report detail setting is completed.	

F34	Report Output Criteria & Date Range	** ALL (Output all transactions of the specified date range)	And (Only transactions fulfil the selected criteria(s) of the specified date range will be outputted)
	2 report output criteria are available: - • All = All data of the selected date duration will be outputted. • And = Only data meets with the criteria selected and inputted will be outputted. Setting procedures: - 1. Press [Func] or [Unit] until the preferred output criteria appears and press [Set]. a. If All is selected, instrument goes to step 2 below. b. If And is selected, name of output criterion and its current setting are displayed. 5 criteria are available, they are: - • OP.Code = Operator number. • C Code = Customer Code. • P Code = Product Code. • Check = Check Result (Lo = Below; OK = Accept; Hi = Above; NG = Lo or HI) • Note = Transaction Note to Alibi Memory. 2. Press [Func] or [Unit] until the preferred parameter appears, Notes: - • Select On to enable that output criterion and then enter/select the criterion value. • Select Off to disable that output criterion. 3. Press [Set] to confirm. 4. Name of the next output criterion is displayed. Repeat the above steps 2 and 3 for all other output criteria until instrument displays Report. Note: - If more than one criterion is selected, only records that meet all selected criteria will be outputted. • Instrument is now in report output date duration setting status. 6 output date duration parameters are available: - • Day = All transaction of a specified date • Month = All transaction records of a specified month • Period = All transaction records within the specified period • All = All transaction records in Alibi Memory. • Last = Last Alibi Record Number Saved. This parameter appears only when And is selected in step 1. This parameter will output all content disregarding the And criteria selected. • Range = Range of the Alibi Record. This parameter appears only when And is selected in step 1. This parameter will output all content disregarding the And criteria selected. 5. Press [Func] or [Unit] until the preferred output date duration parameter appears and press [Set]. • If Day is selected, input the requested date value and press [Set] to output. • If Month is selected, input the first date of the requested month value (e.g., 19.12.01 for the month of December 2019) and press [Set] to		

	output. • If Period is selected, input the requested starting date value and press [Set] and then input the requested ending date value and press [Set] to output. • If All is selected, press [Set] to output. • If Range is selected, input the first ABNR and press [Set], then input the last ABNR and press [Set] again to output. • If Last is selected, simply press [Set] to output.		
F36	Expiry Duration	Expiry duration = **0 ~ 9999 Notes: - • XXX = Today + xxx day • **0 =Today • 1 = Tomorrow • 14 = Today + 14 days Setting procedures: - 1. Enter expiry duration then press [Set] to confirm and save. 2. To clear an expiry duration, press [CE/x10] then press [Set].	
F37	Customized Operation Settings PLU Auto Search via Barcode Scanner Input	C Code (Auto Search by Customer Code) **Off (Disable)/On (Enable)	P Code (Auto Search by Product Code) **Off (Disable)/On (Enable)

7. Recommended Setting Procedures for User

1. Power off this instrument and remove the power adaptor.
2. Complete all hardware connections with peripherals.
3. Apply power adaptor and power on instrument.
4. Go to F1 and check the internal count value. Internal count value should increase when extra loads are applied. Likewise, the internal count value decreases when loads are removed.
5. Go to F2 and check and make sure no display segments or indicators are missing.
6. Go to F3 and make sure that capacity x division is correctly set.
7. Go to F4 to check and set date format and value.
8. Go to F5 to check and set the time value.
9. Go to F6 to do system initialization.
10. Check and set all other operation parameters from F7, F8, F9.... F37 according to the numeric sequence of the internal function number.
11. Conduct test runs to determine if the above settings are the best suited to the application requirements. If not, set the corresponding parameters again.
12. If Alibi memory is used, contact your dealer for support.

Always contact your dealer for product information, after-sales service, and questions when in doubt.

8. UART & Comport Settings

8.1 UART Description

To facilitate communication with other peripherals via various methods, this instrument is with 5 communication interfaces (UART 0 ~ 1, Bluetooth, WIFI, USB) Refer to the below table for transmission type and assigned comport number.

UART #	Transmission Type	Connected to	Remark
UART 0	RS232	Comport 0	Standard Accessory
UART 1	RS232	Comport 1	
Bt	Bluetooth	N.A.	Optional Accessory
WIFI	WIFI	N.A.	
USB	USB Type C	Reserved	

Note: - only one transmission type can be selected for each UART #.

Setting procedures: -

1. Go to F16 and press **[Set]**.
2. Name of the current interface appears.
3. Press **[Func]** until the preferred interface name appears and press **[Set]**.
4. Instrument displays the current transmission type.
5. Press **[Func]** until the preferred transmission type appears and press **[Set]** to confirm. Depending on the transmission type, maximum 8 parameters are available: -
 - Off = Disabled.
 - Auto 1 = Auto print when weight is stable.
 - Auto 2 = The highest stable weight value (of a weighing process) will be printed when all loads are removed (and the gross weight returns to zero or minus).
 - Auto 3 = The last stable weight value (of a weighing process) will be printed when all loads are removed (and the gross weight returns to zero or minus).
 - Manual = Manual output by pressing **[Print/M+]**.
 - PC = Continuous or selected periodic output of real-time result according to the predefined format.
 - CMD = Command communication with computer.
 - Scanner = Barcode Scanner.

Notes: -

- If PC/CMD/Scanner is set, refer to paragraph 8.2 for the remaining settings.
 - If Auto 1 ~ 3 or Manual is set, refer to **paragraph 8.3** for the rest setting.
6. Repeat the above steps 1 ~ 5 for all other UARTs.

8.2 Parameters Table for PC/Command/serial Scanner

Step No.	Set Item	Parameters	PC	CMD	Scanner
1	Baud Rate	1200 ~ 921600 in 11 steps Default = 115200	■	■	■
2	Parity	None/Odd/Even Default = None	■	■	■
3	Data Length	7 or 8 bit Default = 8 bit	■	■	■
4	Protocol Type (Note G)	Protocol 0 ~ 9 & Custom Default = Protocol 1	■	Completed	Completed
5	Transmission Interval (Note A)	0 ~ 300 (second) in 10 steps Default = 0	Completed		

8.3 Parameters Table for Auto 1 ~ 3 & Manual

Step No.	Set Item	Parameters	Auto 1	Auto 2	Auto 3	Manual
1	Baud Rate	1200 ~ 921600 in 11 steps Default = 115200	■	■	■	■
2	Parity	None/Odd/Even Default = None	■	■	■	■
3	Data Length	7 or 8 bit Default = 8 bit	■	■	■	■
4	Auto Accumulation (Note B)	Off/On Default = On	■	■	■	■
5	Check Control (Note C)	Off/On Default = Off	■	■	■	■
6	Stability Control (Note D)	Yes/No Default = Yes	■	■	■	■
7	Minimum Output Weight (Note E)	0 ~ 20d Default = 20d	■	■	■	■
8	Output Format (Note F)	Lab 1 ~ Lab 5, LP 50, TSC and Sbarco Default = Lab 2	■	■	■	■
9	Other Procedures		(Note H ~ K)			

Note A: - Transmission interval is the time interval (in second) between each output. 0 = continuous output.

Note B: - On = Auto Memory accumulation enabled.

Off = Auto Memory accumulation disabled.

Note C: - On = (When check function is in effect) Only OK value (value which is within Lo and Hi Limits) will be processed.

Off = (When check function is in effect) Check control is disabled.

Note D: - Yes = Only stable weight will be processed.

No = Transmission is activated when **[Print/M+]** is pressed disregarding the weight stable status.

Note E: - Minimum weight value to be transmitted. No data will be processed if the weight detected is less than the minimum output weight selected here.

Note F: - Output format description: -

- Lab 1 = Output in landscape direction. Refer to **Appendix C** for more information.
- Lab 2 = Output in portrait direction. Refer to **Appendix D & E** for more information.
- Lab 3 = Database output mode. Refer to **Appendix F** for more information.
- Lab 4 = Journal output format with the gross and net weight of each transaction. Refer to **Appendix G** for more information.
- Lab 5 = Journal output format with time and net weight of each transaction. Refer to **Appendix H** for more information.
- LP-50/TSC/Sbarco = Output to LP-50/TSC/Sbarco label printer. Refer to **Appendix I ~ K** for more information.

Note G: - Protocol type description

- Refer to **Appendix A** for Predefined PC Output Prot 0 ~ Prot 9.
- Refer to **Appendix B** for Customized PC Output Protocol.

Note H: - If Lab 1 is set in Print format, select print format: -

- a. STD for predefined output format and press **[Set]** to save, or
- b. Custom for customized output format and press **[Set]** to save.

Hints: -

- If STD is set, then select line number and press **[Set]** to save. Setup is then completed. Line number is the number of transactions sent after which the header will be repeated.
- If CUSTOM is set, refer to Appendix C.2 for other detailed settings.

Note I: - If Lab 2 is set in Print format, select also the number of copies and press **[Set]** to save. Setup is then completed.

Note J: - If Lab 4 / Lab 5 is set in Print format:

1. Instrument displays current statistic data output⁴ (Sd) setting (On / Off). When Sd is set to On, the below statistical results will also be transmitted.
 - Max = Maximum Value
 - Min = Minimum Value
 - Diff = Differentiation (Max – Min)
 - X = Mean (Average)
 - Sd = Standard Deviation. Formula used: $S = \sqrt{\frac{\sum (X - \bar{X})^2}{N}}$
 - Srel = Relative Standard Deviation
2. Press **[Func]** or **[Unit]** until the preferred parameter appears then press **[Set]** to save.
3. At this point, Lab 4 / Lab 5 setup is completed.

Note K: - If LP50/TSC/Sbarco is selected: -

1. Select number of copy (1 ~ 8) and press **[Set]** to continue the below setting,
2. Select label file number (FL1 00 ~ FL1 99) to print in label format group 1 and press **[Set]** to continue the below setting. FL1 00 = current transaction label printing output disabled.
3. Select label file number (FL2 00 ~ FL2 99) to print in label format group 2 and press **[Set]** to continue the below setting. FL2 00 = totalized (MR) data label printing output disabled.

8.4 Heartbeat Connection Check Function for WIFI

In addition to the setting procedures listed on paragraph 8.2 and 8.3, if WIFI is selected, set also the heartbeat connection check (ConChk) parameter. 5 time interval parameters are available: -

- Off (heartbeat connection check function disabled)
- 60 (second)
- 120 (second)
- 240 (second)
- 300(second)

Heartbeat connection check function is used to verify the connection via WIFI is working properly or not.

When this function is enabled, the peripheral connected should send text string *STCCHK# to this instrument within the time interval set.

If the above text string is not received within the time interval set, instrument will display: -

- Fi=Out to indicate WIFI connection with peripheral is interrupted.

8.5 When Bluetooth is selected

Some other settings are required. Contact your dealer for setting information and assistance.

4 Statistic data output calculates weight data only extra statistic data will be output if Sd is set to On.

9. Basic Operation

9.1 Power Instrument On & Off

- To power on: - press **[On/Off]** and then release.
- To power off: - press **[On/Off]** and then release.

To avoid losing data, always turn off the instrument with the **[On/Off]** key.

9.2 Power on Countdown Process

After powered on, instrument goes through the power on countdown process and displays the below information.

1. Software number.
2. Software version number in the format of U XXX.
3. Display all numeric segments and indications.
4. Calibration count value.
5. Parameter set count value.
6. Capacity & division in the format of Max plus 1 division.
7. Depending on the internal function number F28 setting, instrument may ask for operator number input. If this is the case: -
 - Input 4-digit operator number, or
 - Press **[CE/x10]** to skip operator number
8. Press **[Set]** to enter,
9. At this point, instrument is in Weighing mode and is ready for operation.

9.3 Operator Number

If F28 is set to Yes, instrument will ask for operator number input during the power on countdown process.

- Input operator number: - when prompted, input a 4-digit operator number and press **[Set]**.
- To clear operator number: - when prompted, press **[CE/x10]** and press **[Set]**.

Once an operator number is inputted, instrument will transmit the number inputted in Lab 3 ~ 5 output format.

9.4 Warm-Up Time

Allow a warm-up period of not less than 60 seconds after power-on before using.

9.5 Keyboard Lock

When keyboard lock is enabled in F20, only **[Set]**, **[Zero]**, **[Tare]** and **[On/Off]** keys can function during normal operation.

9.6 Loading & Weighing

- Always place an object gently. Excessive force/shock applied may cause unrecoverable damage to the weight sensor.
- It is a good practice to remove all loads after weighing. It will prolong the life of the weight sensor.

9.7 Manual Zero

If zero weight cannot be obtained when unloaded, press **[Zero]**. **Zero Indicator** lights up when instrument is at zero status.

9.8 Tare Functions

9.8.1 Manual & automatic tare

This instrument is equipped with the below various tare functions. These functions can be selected in F12.

- a. Off: - Manual Tare
- b. Auto: - Instrument assumes the first stable weight ($\geq 10d$ or $20d_1$) applied is a container and tare off its weight. When the container is removed and the gross weight is zero, tare effect will be cancelled.
- c. Contin (continuous auto tare): - All stable weight ($\geq 20d$ or $20d_1$) applied will be tared off. When all loads are removed and the gross weight is returned to zero, the tare effect will be cancelled.

Notes: -

- If Contin is selected, instrument will prompt for delay time (0.0 ~ 9.9 second. Default = 1.5 second).
- Delay time is the time duration from when a stable weight is detected until it is tared off.
- Input the preferred delay time and press **[Set]** to save.

9.8.2 Repetitive/multiple tare

This instrument is equipped with multiple tare operation capability. Settings: -

- Set F13 = On to allow multiple tare operation. If it is the case, instrument will permit multiple tare operation, and tare effect can only be cancelled when there is no load .
- Set F13 = Off to disable multiple tare operation. If this is the case, the tare effect can only be canceled when the container is removed, and the gross weight is zero.

9.8.3 Preset tare

Preset tare allows a pre-determined tare weight value to be entered.

9.8.3.1 Introduce a preset tare value

Follow the below procedures to enter a pre-determined tare weight value.

1. Press **[PT]**.
2. Input the pre-determined tare weight value.
3. Press **[Set]** to save and confirm.

After the pre-determined tare value is inputted: -

- Instrument displays the preset tare value input.
- **Net indicator & Data Indicator** appear to indicate the value being displayed is net weight.

9.8.3.2 Cancel a preset tare value

A preset tare value can be canceled by either one of the below methods: -

- Remove all loads and press **[Tare]**.
- Input a zero preset tare value and press **[Set]**.

9.9 Select the Preferred Weight Unit⁵

This instrument supports kg, g, and lb. The desired weight units should be enabled in F9 before use. Contact your dealer if in doubt.

Disregarding the setting of **F9**, weight unit gram (g) is available only when 3 or 4 decimal places (0.000 or 0.0000) is selected in F81. Contact your dealer for more details.

To select the preferred weight unit, press **[Unit]** until the preferred weight unit appears.

The weight unit employed before powering off will be employed again when powered on again.

9.10 Select the Preferred Function Mode⁶

This instrument supports the below-working modes. The abbreviation of each working mode is bracketed.

- Weighing (Weigh).
- Animal Weighing (Ani).
- Quick access to Customer & Product Code Setting (PCd).

Press **[Func]** to enter function selection mode and press **[Unit]** until the abbreviation of the desired working mode appears and press **[Set]** to enter.

The working mode employed before powering off will be employed again when powered on.

9.11 Check Functions^{7 8 9 10}

This instrument is equipped with Lo/Hi check function. Check targets of various working weight value.

5 Changing weight unit during operation will clear all accumulated weight data from memory.

6 Depends on F11 setting.

7 Check function does not support Animal Weighing mode.

8 Check mode will not operate when weight is less than 20d (or 20d1 for dual weighing range/interval mode).

9 Set also F15 for desired Check buzzer output.

10 Refer to F25 of paragraph 6.4 for static and standard check modes.

9.11.1 Input check limits manually

1. Select preferred weight unit and working mode.
2. Press **[Check/PLU]**, then input the Lo limit value.
3. Press **[Set]**, then input the Hi limit value.
4. Press **[Set]**. The Lo and Hi limits are now in effect.

9.11.2 Cancel check limits inputted

Refer to **paragraph 9.11.1** and press **[CE/x10]** when prompted for value in step 2 and 3.

9.11.3 Hints for entering Lo & Hi Limits

1. For typical comparison, set both Lo and Hi limits.
2. To check if the result is lower than or equal to Lo (result $\leq$ LO), set Hi limit = 0.
3. To check if the result is higher than or equal to Hi (result $\geq$ HI), set Lo limit = 0.
4. To check if the result is equal to a specified value, set both Hi limit and Lo limit = the specified value.

9.12 Tri-color Backlight

This instrument is equipped with a tri-color backlight. The 3 colors are yellow, green and red.

- In typical operation, green is used for display illumination.
- When check function is activated: - yellow = Lo; green = OK; red = Hi.

When instrument is powered by built-in rechargeable battery: - Backlight will turn to minimum when weight remains stable/unchanged for 5 seconds. Stable for backlight means ± 5 division variation within one second.

When this instrument is powered by adaptor: - Backlight will remain on.

9.13 Auto Power Saving & Auto Power-off Time

This instrument is equipped with auto power saving and auto power-off time functions. Refer to **F7** in **paragraph 6.4** for more information.

9.14 Extended Display Mode¹¹

When F68 is set to OIML or NTEP, press **[CE/x10]** to temporarily (5 seconds) increase the weighing resolution to 10 times finer. The display keeps flashing when instrument is displaying the extended results.

10. Memory & Data Related Operation

10.1 Memory Accumulation

There are 2 types of Memory Accumulation: -

1. Automatic Accumulation mode, and
2. Manual Accumulation mode.

Maximum accumulation limit is = 8 digits (e.g. 99999999) plus decimal (if any). **Err 28** appears when the maximum accumulation limit is exceeded.

10.1.1 Automatic accumulation¹²

Automatic accumulation is activated when Auto Accumulation is set to On in Auto 1, Auto 2, Auto 3 or Manual mode is selected in F16.

Under the automatic accumulation mode, corresponding results will be accumulated.

10.1.2 Manual accumulation¹³

Manual Accumulation is activated when none of the UART port is assigned with Auto Accumulation = On.

Under the Manual Accumulation mode, press **[Print/M+]** to accumulate the current value to memory.

¹¹ When F68 = OIML or NTEP.

¹² Refer to paragraph 8.3 for setting details.

¹³ Refer to paragraph 8.3 for setting details.

10.1.3 When data is accumulated to memory¹⁴

1. When a result is accumulated to memory, this instrument displays “n____x”. **M+ Indicator** appears to indicate that memory contains stored data. “x” means the total number of transactions accumulated to memory.
2. This instrument returns to normal display status after 0.5 second.

10.1.4 Memory recall & clearance

Accumulation data will be stored in memory and will not be erased by the normal power-off process (by pressing the **[On/Off]** key).

Instrument will erase all accumulated data when: -

- a. Weight unit is changed, or
- b. Working mode is changed, or
- c. A different operator number is inputted during power-on process.

Follow the below procedures to recall and clear accumulation data manually.

1. Remove all loads from weighing platform and make sure that weight value displayed is zero.
2. Press **[Print/M+]** to recall total accumulated weight.
3. Instrument flashes between “A____Y” (Y means number of transactions accumulated) and total accumulated result.
4. At this point: -
 - a. Press **[Zero]** to quit, or
 - b. Press **[CE/x10]** to clear memory. After **[CE/x10]** is pressed, instrument displays Clear, and M+ Indicator disappears to indicate no data is stored in memory.

10.2 Expiry Date

This instrument supports expiry date output. Once expiry duration (in term of day) is inputted in internal function F36, instrument will then convert the duration into expiry date. Expiry date can be recalled for other purposes.

10.3 Machine ID, Group & Operator Numbers

This instrument supports machine ID, group, and operator numbers. Refer to F18 and F28 of **paragraph 6.4** for more information. These numbers will also be added to an individual transaction when saving to Alibi memory.

Once these numbers are inputted, they will be outputted through the assigned comport. These numbers will also be added to an individual transaction when saving to Alibi memory.

10.4 Inputting Numbers, Letters, Symbols via Keyboard

Keyboard on instrument supports only numeric input for:

- a. Product code and description
- b. Customer code and description

To enter letters and certain special symbols, input can be made through a connected computer or smart device.

10.5 Customer/Product Code & Description

Once the customer/product code & description is inputted, it will be printed through the assigned comport. Customer/product code inputted will also be added to an individual transaction when saving to Alibi memory.

Maximum data length as below: -

- Customer Code = 18 digits
- Customer Description = 30 digits.
- Product Code = 18 digits.
- Product Description = 30 digits.

14 When F16 is set to mode Auto1~3, unstable result or result which is less than 20d (20d1 for dual weighing range/interval mode) will not be accumulated to memory.

10.5.1 Entering customer/product code & description manually

1. Go to Customer/Product code setting manual by either one of the below methods.
 - a. If Quick Manual Code Setting function (CPd) in F11 is set to on: -
 - Press **[Func]** for several times until C.P. Code appears and press **[Set]**.
 - Press **[Func]** until the desired mode appears (select C Code for customer code & description or P Code for product code & description) and press **[Set]** to confirm.
 - b. If Quick Manual Code Setting function (PCd) in F11 is set to Off: -
 - Go to F19 and press **[Set]**.
 - Press **[Func]** until the desired mode appears (select C Code for customer code & description or select P Code for product code & description) and press **[Set]** to confirm.
2. Instrument displays previous code inputted (if any).
3. To move cursor to one place left/right, press **[Func]**.
4. Input the preferred code (maximum 18 digits) and press **[Set]** to confirm.
5. Instrument prompt for description.
6. Input the preferred description (maximum 30 digits) and press **[Set]** to confirm.
7. Instrument displays Done. The code and description entered is now employed.
8. To go to other internal functions, press **[Func]** or **[Zero]** to quit to operation status.

11. Weighing Mode

1. Refer to **paragraph 9.9** on how to select the desired weight unit.
2. If zero weight cannot be obtained when unloaded, press **[Zero]**. After **[Zero]** is pressed, the **Zero Indicator** will appear¹⁵.
3. Always place an object onto platform gently. Excessive force/shock applied to platform may cause unrecoverable damage to the weight sensor inside platform.
4. The weight of the object is displayed automatically.
5. It is a good practice to remove all loads from platform after weighing. It will prolong the life of the weight sensor.

12. Animal Weighing Mode^{16 17}

12.1 Description of Animal Weighing Mode

Animal Weighing mode is used to weigh live animals.

12.2 Animal Weighing Mode Settings

1. At Weighing mode, select the desired weight unit. Refer to **paragraph 9.9** on how to select the desired weight unit.
2. Go to Animal Weighing mode.
3. Refer to **paragraph 10** if data related functions are needed.
4. Press **[Set]** then **[Unit]** to select filter speed. 5 parameters (FLT 1 ~ 5) are available: -
 - FLT 1 = Fastest speed with the lowest accuracy.
 - FLT 3 = Normal speed. Recommended setting for most animal weighing applications.
 - FLT 5 = Slowest speed with the highest accuracy.
5. Press **[Set]** to save and to select weight release variation percentage. 10 parameters are available (Off ~ 20%).
 - rE oFF = auto-release disabled except all loads are removed.
 - rE 2 = auto-release when weight varies $\geq 2\%$ of rated capacity (or W1 for dual weighing range/interval mode) or when all loads are removed.
 - rE 20 = auto-release when weight varies $\geq 20\%$ of rated capacity (or W1 for dual weighing range/interval mode) or when all loads are removed.
6. Press **[Unit]** key to select the preferred weight release variation and press **[Set]** to save.
7. Instrument is now ready for animal weighing application.

¹⁵ Maximum weight value can be zero depends on F65 setting. Contact your dealer for detail.

¹⁶ Animal Weighing mode will not operate when weight is less than 20d (or 20d1 for dual weighing range/interval).

¹⁷ Check Function does not support Animal Weighing mode.

12.3 Start Using Animal Weighing


1. Get an animal on.
2. Instrument will calculate and hold the weight of an animal. The result being held flashes.
3. In case more animals have to be weighed in the same transaction, get other animals on. An updated weight will be calculated, held and displayed¹⁸ as above step 2.
4. To refresh the weight reading manually, press **[CE/x10]**.

13. Near Zero Function Description

Near zero value is a useful function for checking. It is used to avoid unnecessary/false Lo signal output during loading and unloading.

Hi/OK/Lo comparison will only start when weight reading exceeds the preset near zero value. Refer to the below diagram for more illustration.

Near Zero Value Illustration Diagram



14. Barcode Scanner

This instrument supports both serial barcode scanner and CT10 Bluetooth barcode scanner.

14.1 Barcode Scanner Setup

14.1.1 Serial barcode scanner setup

1. Serial barcode scanner should be connected to comport 0.
2. Refer to **paragraph 8.2** for scanner settings.

14.1.2 CT10 serial barcode scanner setup

1. To use this instrument with a CT10 Bluetooth scanner, the optional BT2.0 module must be equipped. Contact your dealer for assistance.
2. To enable CT10 communication, refer to the setting procedures in **paragraph 8.1** and: -
 - a. Select BT at step 3.
 - b. Select Scanner at step 4.
3. Pairing this instrument with CT10
 - a. Restart this instrument and CT10.
 - b. Scan the Enter Setup barcode on the left.
 - c. Scan the Enable SPP barcode on the left.
 - d. Scan the Password 10010 barcode on the left.
 - e. Scan the Exit with Save barcode on the left.

¹⁸ Provide that extra weight added/removed fulfills the weight release variation value listed on step 5 of **paragraph 12.2**.

Notes: -

- After the above is done, pairing will be completed (and confirm with a short high tone from CT10) within 10 seconds depends on connection status. To ensure pairing is successful, scan the Zero key barcode in paragraph 14.2 when instrument is unloaded. Instrument should respond with a beep once the Zero key barcode is scanned.
- In case of mis-operation, scan the Exit without Save barcode, then repeat step **a ~ e** above.
- For other CT10 settings, refer to the user guide which comes with the CT10.

The barcode scanner is used to: -

- a. introduce an operation key,
- b. input an operator number,
- c. input a customer/product code. The scanned code may also trigger the PLU auto search function. Refer to paragraph 14.4 for more information.

14.2 Barcode Scanner Functions

14.2.1 Simulating operation key

To simulate **[Zero]**, **[Tare]**, and **[Print/M+]** key inputs, simply scan the corresponding barcodes below.



14.2.2 Entering Customer/Product Code & Operator Number

Customer/product and operator number can be inputted through barcode scanner. Procedures: -

1. Define first data nature (customer/product code or operator number) of data by scanning first one of the below 3 input targets.
2. Once an input target is scanned, all following scanner data inputs will be considered as the same data nature.
3. To change the scanner input target, scan the desired input target barcode, followed by the customer, product, or operator number barcode.

Input Target Barcodes



14.3 Embedding Input Target Information into a Barcode/RFID Tag

The procedure for scanning the input target mentioned in paragraph 14.2.2 can be skipped by adding the below prefix to a barcode.

In case RFID tags are used, include the following prefixes to the RFID tag content to bypass the input target scan:

- %PC% for product code. For example, %PC%412985 for product code 412985.
- %CC% for customer code. For example, %CC%Fidelity for customer code Fidelity.
- %OP% for operator code. For example, %OP%1234 for operator number 1234.

14.4 Barcode Scanner & Auto Database Search

When a customer or product code is scanned, the instrument automatically searches the appropriate PLU database based on the F37 setting.

- F37 = ON: The instrument searches within the Production Settings PLU database.
- F37 = OFF: The instrument searches within the Customer/Product Code & Description in database.

Search Sequence & Actions

Once a customer or product code is scanned: -

- a. If F37 is set to **On**, instrument searches the code scanned in the Production Settings PLU database.
 - If the scanned code exists, the corresponding settings are immediately applied.
 - If the code does not exist, then instrument will employ the scanned code.
- b. If F37 is set to Off, the instrument will not search the database.

15. Label Printing¹⁹

This instrument supports the below label printer models: -

- LP50 by Datecs (www.datecs.bg/en)
- TDP247, TDP345, TTP247, TTP345 by TSC (www.tscprinters.com)
- All models with serial communication by Sbarco (<http://www.Sbarcotech.com>)

Notes: -

- Set all preferred operation parameters and label printer model according to **paragraph 8**.
- Refer to **Appendix I** for TSC printer installation, setup procedures, and detail on creating and uploading labels to the TSC printer by Bartender Label software.
- Refer to **Appendix J** for Sbarco Printer Installation, setup procedures, and detail on creating and uploading label to Sbarco printer by BarDrawer software.
- Refer to **Appendix K** for detail on label programming and illustration samples.

15.1 Label Format Groups & Label File Names

Two label format groups are available: -

- FL1 (label file group 1), and
- FL2 (label file group 2).

15.1.1 FL1 (Label Format Group 1)

FL1 (format group 1) is used to print the data of the current and individual transactions. 100 printout selections (00 ~ 99) are available in format group 1.

To trigger the preferred label to be printed, label files stored in the printer for this format group 1 must have a file name of AA01, AA02, AA03.... AA99.

- FL1 00: - Select this to disable current transaction label printing.
- FL1 01: - Select this to print label file AA01 stored in the printer.
- FL1 02: - Select this to print label file AA02 stored in the printer.
-
- FL1 98: - Select this to print label file AA98 stored in the printer.
- FL1 99: - Select this to print label file AA99 stored in the printer.

28 WIFI and Bluetooth do not support label printing.

15.1.2 FL2 (Label Format Group 2)

FL2 (format group 2) is used to print the totaled (MR) data.

100 printout selections (00 ~ 99) are available in format group 2. To trigger the preferred label to be printed, label files stored in the printer for this format group 2 must have a file name of BB01, BB02, BB03.... BB99.

- FL2 00: - Select this to disable totaled (MR) data label printing.
- FL2 01: - Select this to print label file BB01 stored in the printer.
- FL2 02: - Select this to print label file BB02 stored in the printer.
-
- FL2 98: - Select this to print label file BB98 stored in the printer.
- FL2 99: - Select this to print label file BB99 stored in the printer.

15.2 Repetitive Printout

This instrument supports repetitive printouts under Manual print mode. Press **[Print/M+]** for additional printout copies.

Conditions and criteria as below: -

- a. When Auto Accumulation is set to On: Repetitive print is only possible when the actual weight being displayed is equal to the weight value of the 1st printout.
- b. When Auto Accumulation is set to Off: Repetitive print is possible if minimum output weight set is matched and when **[Print/M+]** is pressed.
- c. The weight value of repetitive printout will not change the total accumulation result. Only the weight value of the 1st printout will be accumulated to memory.

16. Alibi Transaction Memory & Management Report

16.1 Alibi Memory Description

This instrument is equipped with Alibi memory to record all individual transaction records. Management reports can be generated based on data saved in transaction memory, and: -

- The criterion set in F71 (distributor password is needed to access this internal function), and
- The format set in F33, and
- The search criteria and time duration set in F34.

Notes: -

- The Alibi memory is independent to those data obtained through memory accumulation (e.g., manual memory accumulation by pressing **[Print/M+]** key and auto accumulation result by ACC = On in transmission type Manual and Auto 1 ~ Auto 3) during an operation.
- Maximum records can be saved = 131,072 transactions.
- When remaining memory is low: - Instrument displays Li xxx in power on countdown process. xxx is the number of memory remains before instrument starts overwriting historical records.
- When memory is full: - Instrument overwrites old records with new records based on first in first out principle.

An Alibi Management report is constructed of the followings: -

- a. Report Title, which shows the report output data range and search criteria.
- b. Report Header explains the nature of an output column.
- c. Content of Individual transactions.
- d. Footer, which shows 4 different kinds of totaled results. Refer to **paragraph 16.6** for more information.

To enable/disable Title, Header, and Footer output, simply select **On** or **Off** when asked. Refer to step 5 of F33 in **paragraph 6.4** for settings.

Alibi Management Report Construction Illustration

2025-11-11 Daily Report										Title										Header																			
Sys. Seq	Opr	Mode	Mac	MacGp	Date	Time	Ccode	C Description	Pcode	P Description	Gross	Tare	Net	Unit	Low	High	Check Target	Result	Note	Checksum																			
157	8888	0	91	22	2025/11/11	14:26:37	Customer 1	Customer Description 1	Product 1	Product Description 1	2.498	0.75	1.748	kg	2.499	2.501	kg	Below	2333	80																			
158	8888	0	91	22	2025/11/11	14:27:08	Customer 1	Customer Description 1	Product 1	Product Description 1	2.501	0.75	1.751	kg	2.499	2.501	kg	Below	2333	6B																			
159	8888	0	91	22	2025/11/11	14:27:10	Customer 1	Customer Description 1	Product 1	Product Description 1	2.501	0.75	1.751	kg	2.499	2.501	kg	Below	2333	65																			
160	8888	0	91	22	2025/11/11	14:27:12	Customer 1	Customer Description 1	Product 1	Product Description 1	2.501	0.75	1.751	kg	2.499	2.501	kg	Below	2333	5F																			
161	8888	0	91	22	2025/11/11	14:27:14	Customer 1	Customer Description 1	Product 1	Product Description 1	2.501	0.75	1.751	kg	2.499	2.501	kg	Below	2333	62																			
Item : 5																																							
Total Net : 8.752 kg																																							
Total Tare : 3.750 kg																																							
Total Gross : 12.502 kg																																							
2025/11/11 14:27																																							
Footer										Content of Individual Transactions																													

16.2 Define when a Transaction Data is saved to Alibi memory

It is important to first define when transaction data should be saved to Alibi memory during system setup. To do so, go to F71 (distributor is needed) and select the preferred parameter. 6 parameters are available.

- Off = No transaction will be recorded.
- Auto 1 = All stable weight (starts from gross zero or minus) is recorded by the system.
- Auto 2 = The highest stable weight value of a weighing process is recorded by the system (when all loads are removed and the gross weight returns to zero or minus).
- Auto 3 = The last stable weight value of a weighing process is recorded by the system (when all loads are removed and the gross weight returns to zero or minus).
- Manual = Transaction is recorded by the system when **[Set]** is pressed.
- ACC = Transaction is recorded by the system when a new accumulated data is created or manually.

16.3 Adding Short Note to Alibi Management Report

A 4-digit numeric short note can be added to an individual transaction when saving to Alibi memory. Follow the below procedures to create such note: -

- Make sure that Note is set to On in F11.
- During operation status, press **[Func]**.
- Press **[Unit]** until Note appears.
- Press **[Set]**.
- Instrument displays **nt.xxxx**. xxxx is the current short in effect.
- To change, input a new 4-digit value, then press **[Set]** to save and return to normal operation.

Notes: -

- the short note inputted will remain valid until changed or canceled.
- To clear short Note information, press **[CE]** in step 6 above.

16.4 Checksum

To ensure the content of each individual record outputted and received are identical, a 2-digit checksum can be included at the end of each individual record when outputting. Checksum method used is = Simple sum method & mask 0xFF.

Enable checksum output

- In F33, select All to enable all content output, including checksum, in detail setting, or
- In F33, select On when CHKS (checksum) appears during Custom output setting.

Disable checksum output

To disable the checksum output, Select Off when CHKS (checksum) appears during Custom output setting.

16.5 Output & Settings for Alibi Memory & Management Report

Complete both 2 procedures below to output the management report.

- Define the report output UART number and report content in F33. Refer to **F33 of Internal Function Table** in **paragraph 6.4** for more information.
- Define search criteria and date range in F34. Refer to **F34 of Internal Function Table** in **paragraph 6.4** for more information. Multiple search criteria are acceptable based on condition "AND". For example, Operator Code number XXXX and Product Code YYYY. All transactions which fulfill both these 2 criteria will be outputted.

16.6 Totalization

Except date range "All" is selected in F34, instrument will output the totalized data of the below result at the end of the output.

- Total number of transactions of the date range
- Total Net Weight
- Total Tare weight
- Total Gross Weight

Notes: -

- a. During code searching, instrument assumes all customer and product codes are unique.
- b. If duplicate codes exist, the instrument applies the first matching record found.
- c. Production Settings PLU employed before powered off will be employed upon instrument restart.

17. Data Output Protocols & Formats

This instrument supports various PC data output protocols and output formats. Refer to the below paragraphs and **paragraph 8** for more information and setting procedures.

17.1 PC Output Protocols

- 10 predefined PC Output Protocols. Refer to **Appendix A** for more information.
- 1 customized Output Format. Refer to **Appendix B** for more information.

17.2 Data & Print Formats

17.2.1 Predefined output formats

5 predefined output formats (Lab1 ~ Lab 5). Refer to the below Appendixes for more information.

- Lab 1 Output Format. Refer to **Appendix C** for more information.
- Lab 2 Standard Output Format. Refer to **Appendix D** for more information.
- Lab 3 Output Format. Refer to **Appendix F** for more information.
- Lab 4 Output Format. Refer to **Appendix G** for more information.
- Lab 5 Output Format. Refer to **Appendix H** for more information.

17.2.2 Lab 2 customized output format

This instrument supports customized Lab 2 output format. Refer to **Appendix E** for more information.

18. Production Settings PLU

This instrument supports 100 Production Settings PLU for each of the below weight units: -

- kilogram (kg)
- gram (g)
- pound (lb)

Each Production Settings PLU contains various operation parameters. Refer to **Appendix R.2** for detailed information about these operation parameters.

18.1 Create & Save Production Settings PLU

Production Settings PLU can only be created and saved to the instrument by computer commands and by either of the below methods: -

- a. Individual PLU creation and saving: - by computer command. Refer to **Appendix R** for more information.
- b. Bulk creation and saving: - by computer using the Production Settings PLU generator file. This generator file and the user guide are available for download at <https://www.fm.com.tw/resource/driversnsoftwares>.

18.2 Recall a Production Settings PLU

Use either one of the below methods to recall a Production Settings PLU. The Production Settings PLU employed before powering off will be employed again when powered on.

18.2.1 Keyboard method²⁰

1. At Weighing mode, select the desired weight unit. Refer to **paragraph 9.9** on how to select the desired weight unit.
2. Press and hold **[Check/PLU]**.
3. Instrument displays Recall, then the PLU entry page.
4. Input the preferred Production Settings PLU number, then press **[Set]**.
5. The selected Production Settings PLU is now recalled, and the **Production Settings PLU Indicator** appears.
6. To shift to another Production Settings PLU, repeat above steps 1 ~ 4.

Note: When a blank Production Settings PLU is recalled, Err 46 appears.

18.2.2 Barcode scanner method

1. In F37, make sure that the proper code is set to On. i.e.,:-
 - If a Production Settings PLU is recalled by customer code, then C Code in F37 should be set to On.
 - If a Production Settings PLU is recalled by product code, then P Code in F37 should be set to On.
2. At Weighing mode, select the desired weight unit.
3. Scan the barcode, which contains the desired customer or product code.
4. The Production Settings PLU of the code scanned is now recalled, and the **Production Settings PLU Indicator** appears.
5. To shift to another Production Settings PLU, repeat above steps 1 ~ 3.

Note: When the customer/product code scanned does not exist in any Production Settings PLUs, **Production Settings PLU Indicator** will not appear.

18.2.3 Computer command method

Refer to **Appendix T** for more information.

18.3 New Code Scanned/Inputted when a Production Settings PLU is Running

18.3.1 In case new customer/product code is by barcode scanner

Refer to **paragraph 14.4** in case a new code is scanned when a Production Settings PLU is running.

18.3.2 In case new code/description is inputted by keyboard

1. **Production Settings Indicator** disappears.
2. All settings of the last Production Settings PLU used remain valid except for the new code/description inputted.

18.4 To quit from the Current Production Settings PLU.

18.4.1 Keyboard Method

1. Input **00** for PLU number at step 4 of **paragraph 18.2.1**.
2. Production Settings PLU Indicator disappears, and all operation settings become default ones.

18.4.2 Scanner method

To quit completely the current production PLU settings, use the keyboard method as per **paragraph 18.4.1**.

²⁰ Changing weight unit or working mode will cancel the current Production Settings PLU in use.

19. Commands

The following types of command are available: -

- a. Keyboard commands are used to simulate key entries on keyboard.
- b. Execution commands are used to execute an action.
- c. System parameter & operation entry setting commands are used to send system parameters and operation entries to this instrument.
- d. System parameter reading commands are used to read system parameters.
- e. Operation entry reading commands are used to read those operation information inputted (e.g., date, time, product, and customer codes), current and accumulated operation results.
- f. Operation result reading commands are used to read current and accumulated operation results.
- g. Production Settings PLU saving commands are used to create and save customized operation settings to PLU.
- h. Production Settings PLU reading commands are used to read customized operation settings saved in PLU and in effect.
- i. Production Settings PLU execution commands are used to recall a Production Settings PLU number and bring it to immediate effect.

Commands can be sent to this instrument from a computer through any standard communication program. Refer to **Appendix L** to **T** for more information on the above command types.

The UART port assigned for command communication should be set to CMD in F16. Refer to **paragraph 8.2** for setting details and procedures.

20. Built-in Battery & Recharging

20.1 Battery Operation Time

The Battery Power/Level Indicator displays the remaining battery power of the built-in rechargeable battery.

20.2 Symbols & Remaining Power



Full Battery: $\geq 6.3V$.



2 Blocks: $\geq 6.0V$ (Battery level~75%).



1 Block: $\geq 5.7V$ (Battery level~20%).



Frame only: $< 5.7V$ (Battery level is less than 15%).

20.3 Battery Recharge

When  appears, it means that the built-in rechargeable battery is at low voltage status. It is recommended to recharge as soon as possible.

To protect the built-in rechargeable battery, this instrument will be powered off automatically when battery is at an extremely low level. If this is the case, do not attempt to power this instrument on. Recharge this instrument immediately. Failure to do so may cause unrecoverable damage to the built-in rechargeable battery.

Battery charging status is shown by the Battery Power/Level Indicator: -

- Progressing: - Recharging in process.
- Flashing  : - Recharge completed.

Battery recharging is possible during operation. Overcharge protection circuit is inside to prevent battery damages from overcharging.

21. System & Error Codes

Code	Description
Err 1	Time value error
Err 2	Date value error
Err 3	Exceed manual zero
Err 4	Offset out of range/unstable during power on (5 minutes for OIML and NTEP mode)
Err 5	Load cell not detected
Err 6	Tare operation error
Err 7	Logic error. Hi limit is lower than Lo limit (and Hi is not = 0)
Err 8	Logic error. Lo limit is higher than Hi limit (and Hi is not = 0)
Err 13	Exceed maximum power on zero
Err 19	Capacity or division setting error (Division set is higher than 10000d)
Err 22	Manual Zero and Tare stability error
Err 23	Capacity setting error, Capacity 1 > Capacity 2
Err 24	Division setting error, e1 > e2
Err 25	Span gain is too low
Err 26	Not able to obtain stable status for longer than 10 sec
Err 27	- The calculated value per e of Cal 2 varies more than 1% as of Cal 1. Probably caused by a load cell problem. - The mass value of Cal 2 is less than 150% of Cal 1
Err 28	The maximum accumulation limit is exceeded
Err 29	Standard deviation data exceed memory size (300 transactions).
Err 30 ~ 33	WIFI command execution error
Err 34	Cannot communicate with WIFI module
Err 35, 36	WIFI command execution error
Err 38, 39	WIFI command execution error
Err 42	Cannot communicate with Bluetooth module
Err 43	Bluetooth module execution command error
Err 46	Customized Operation PLU number does not exist
Err 50	Value entered exceeds maximum value
Err 98	Alibi memory error
Err 99	Parameter flash error
--oL--	Overload (Gross weight is more than Max plus 9d)
HALT	Major system error detected. Power off instrument and remove power adaptor immediately. Then check load cell connection and system power status.
UndEr	Negative Weight value exceeds display range
Reboot	Important parameters have been changed. Power off and then power on instrument again to reboot.
-----	Negative Tare value exceeds display range
Fi = Out	No heartbeat signal is received via WIFI within the time interval set.

22. Daily Care & Maintenance

1. Clean this instrument with a soft, damp cloth. If necessary, use a mild detergent in water.
2. Do not use any harsh, abrasive material, acetone, volatile solvent, thinner, or alcohol for cleaning.
3. Verify the accuracy of this instrument periodically. Re-calibrate if necessary. In some countries, calibration requires an authorized/qualified agent. Contact your dealer for more information.
4. Store this instrument in a dry and clean place.
5. Recharge battery before and every 4 months during long time storage.

Appendix A: - Pre-Defined PC Output Protocols

A.1 Data Abbreviation Table

Data Code	Description
,	Comma
+, -	• Polarity Sign • Positive = space. Negative = minus (-)
P	• Polarity Sign • Positive = 0. Negative = minus (-)
A	7 digits ADC value with leading space
G/N	Gross/Net • NT = Net weight • GS = Gross weight
NET	Net Weight
S	Status Code • ST for Stable • US for unstable
R	Reversed 7-digit weight value, including the location of the decimal point. If there is no decimal point, then the last character = space.
SP	Space
SWA	Status Word A
SWB	Status Word B
U	Weight Unit • kg = kilogram • lb = pound • g(space) = gram
W	7 digits weight value including location of decimal point. If there is no decimal point, then the first character = space.

A.2 Output Formats Tables

Protocol 0 Output Format

Position	1	2	3	4	5	6	7	8	9	10
Data	+, -	A	A	A	A	A	A	A	CR	LF

Protocol 1 Output Format

Position	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
Data	S	S	,	G/N		+, -	W	W	W	W	W	W	W	,	U	U	CR	LF

Protocol 2 Output Format

Position	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
Data	STX	SWA	SWB	SP	Field 1 (Net Weight)						Field 2 (Tare Weight)						CR

Protocol 3 Output Format

Position	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
Data	SOH	STX	SP	+, -	W	W	W	W	W	W	W	SP	U	U	SP	SP	SP	SP	CR	LF

Protocol 4 Output Format

Position	1	2	3	4	5	6	7	8	9
Data	=	R	R	R	R	R	R	R	P

Protocol 5 Output Format

Position	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
Data	S	S	,	G/N		,	+, -	W	W	W	W	W	W	W	U	U	CR	LF

Protocol 6 Output Format

Position	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
Data	N	E	T	SP	+, -	W	W	W	W	W	W	W	U	U	CR	LF

Protocol 7 Output Format

Position	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19
Data	SOH	STX	SP	+, -	W	W	W	W	W	W	W	SP	U	U	SP	SP	SP	CR	LF

Protocol 8 Output Format

Position	1	2	3	4	5	6	7	8	9	10
Data	STX	+, -	W	W	W	W	W	W	W	ETX

Protocol 9 Output Format

Position	1	2	3	4	5	6	7	8	9	10	11	12
Data	STX	+, -	SP		W	W	W	W	W	U	U	ETX

Appendix B: - Customized PC Output Protocol

This instrument supports customized PC output protocol. Under this mode: -

- 2 data separation types
- 7 control codes, and
- Various transaction data

are available from instrument.

B.1 Customized PC Output Protocol Setting Procedures

1. At Weighing mode, go to F16 and select the preferred UART number depends on the output comport number.
2. Select the preferred transmission type.
3. Select PC, then set baud rate, parity, and data length.
4. Select Custom in Protocol page. Press **[Set]**.
5. Instrument displays one of the data separators.
6. Press **[Unit]** to shift between data separator Comma (comma) and SemiCo (semicolon) and press **[Set]**.

Notes: -

- Data separator is a symbol inserted between transaction data and used by a computer program to separate various data.
 - No data separator is inserted between in front or after control commands.
 - Separator in front and after a control code will not be surpassed. For example: -
 - STXdata,data,dataETX
 - Exception of above is when control codes are in between 2 data. For example: -
 - data,CR LF data
7. Instrument displays item number, then followed by the content page.
Note: - Item number means the output sequence, e.g., Item 1 = the first content to output, Item 3 = the third content to output.
 8. Press **[Func]** or **[Unit]** until the preferred content appears and press **[Set]**. Refer to **table B.2** for more information.
 9. Repeat steps **7** and **8** to include other transaction data or control.
 10. To complete and save a customized output, select **End** and press **[Set]**.
 11. Then select the output time interval. Refer to **paragraph 8.2** for more information.
 12. Press **[Set]** to save.

B.2 Customized PC Output Content Table

Symbol	Explanations	Nature	No. of Digits	Remarks
CoMMA	Comma	Data Separator	1	Select either one
SemiCo	Semicolon		1	
Cr LF	HEX Code 0D 0A	Control Code	2	
Cr	HEX code 0D		1	
LF	HEX code 0A		1	
SOH	HEX code 01		1	
STX	Hex code 02		1	
ETX	Hex code 03		1	
Status	Weigh Status	Transaction Data	2	- ST = Stable - US = Unstable - OL = Overload
nT-GS	Net/Gross Sign		2	NT = Net/GS = Gross
Date	Date of Output		10	
Time	Time of Output		8	
Net	Net Weight		8	Numeric value only, without weight unit
Tare	Tare Weight		8	
Gross	Gross Weight		8	
Unit	Weight Unit		2	- kg = Kilogram (space)g =gram
H ref	Hi Limit		8	8-digit including decimal (if any)
L ref	Lo Limit		8	8-digit including decimal (if any)
Ck res	Comparison Result		2	Lo/Ok/Hi/Grade Result for grading
id	Machine ID		2	00 ~ 98, Blank = None
Group	Machine Group Number		2	00 ~ 99, Blank = None
Op Code	Operator Number		4	0000 ~ 9999, Blank = None
P Code	Product Code		1 ~ 18	Blank = not inputted
P_Desc	Product Description		1 ~ 30	Blank = not inputted
C Code	Customer Code		1~ 18	Blank = not inputted
C_Desc	Product Description		1 ~ 30	Blank = not inputted

Trans	No. of accumulated transaction		8	Blank = none
ACC	Total Accumulated Weight		8	Blank = none
Animal	Weight Hold (Animal Weighing)		8	8-digit including decimal
t_GS	Accumulated Gross Weight		8	8-digit including decimal
t_Tare	Accumulated Tare Weight		8	
Expiry	Expiry Duration		8	
Note	Short Note		4	
Abnr	Last Alibi Record Number Saved. <i>Do not use this parameter if Alibi memory function is not activated.</i>		8	
CHKS	Check Sum of all content at the left side		2	
End	End of Input	Control Code	None	

Appendix C: - Lab 1 Output Formats

No header generated when line number is set = 00. See below tables for print format illustrations and explanations.

C.1 Weighing & Animal Mode Predefined Output Format Illustration

Date	Time	Seq	Mode	Net	Tare	Gross	Total	Result
2025-06-28	20:36:28	1	W	1.500kg	0.000kg	1.500kg	1.500kg	Accept
2025-06-28	20:36:30	2	W	1.500kg	0.000kg	1.500kg	3.000kg	Accept
2025-06-28	20:36:31	3	W	1.500kg	0.000kg	1.500kg	4.500kg	Accept
2025-06-28	20:36:33	4	W	3.000kg	0.000kg	3.000kg	7.500kg	Above

C.2 Customized Lab 1 Output

This instrument supports customized Lab 1 output format. Under this output: -

- 2 data separation types
- 7 control codes, and
- Various transaction data

are available from instrument. Refer to table B.2 for detail.

C.2.1 Customized Lab 1 Output Setting Procedures

1. Select Custom in output format page. Press **[Set]**.
2. Instrument displays one of the data separators.
3. Press **[Unit]** to shift between data separator Comma (comma) and SemiCo (semicolon) and press **[Set]**.

Notes: -

- Data separator is a symbol inserted between transaction data and used by a computer program to separate various data.
- No data separator is inserted between in front or after control commands.
- Separator in front and after a control code (C1 ~ C6) will not be surpassed. For example: -
- STXdata,data,dataETX
- Exception of above is when control codes are in between 2 data. For example: -
- data,CR LF data

4. Instrument displays item number, then followed by the content page.

Note: - Item number means the output sequence, e.g., Item 1 = the first content to output, Item 3 = the third content to output.

5. Press **[Func]** or **[Unit]** until the preferred content appears and press **[Set]**. Refer to table B.2 for detailed selectable output content information.
6. Repeat steps 4 and 5 to include other content to output
7. To complete and save a customized output, select **End** and press **[Set]**.
8. Then select line number and press **[Set]** to save. Line number is the number of transactions sent after which the header will be repeated.
9. Setup is then completed.

Appendix D: - Lab 2 Standard Output Format

See below tables for print format illustrations and explanations.

D.1 Weighing Mode Illustration

Time	21:39:17	<i>Time of Output</i>
Date	2025-06-28	<i>Date of Output</i>
Seq	1	<i>Accumulate Sequence No.</i>
Name	Customer Code	<i>Customer Code (if inputted)</i>
Customer Description		<i>Customer Description (if inputted)</i>
Pcode	Product Code	<i>Product Code (if inputted)</i>
Product Description		<i>Product Description (if inputted)</i>
Net	3.006kg	<i>Net Weight</i>
Tare	0.000kg	<i>Tare Weight</i>
Gross	3.006kg	<i>Gross Weight</i>
Total	3.006kg	<i>Total Accumulated Net Weight</i>
High	3.500kg	<i>Hi Limit (if inputted)</i>
Low	2.500kg	<i>Lo Limit (If inputted)</i>
Accept		<i>Check Result</i>

D.2 Animal Weighing Mode Illustration

Time	21:43:12	<i>Time of Output</i>
Date	2025-06-28	<i>Date of Output</i>
Seq	1	<i>Accumulate Sequence No.</i>
Name	Customer Code	<i>Customer Code (if inputted)</i>
Customer Description		<i>Customer Description (if inputted)</i>
Pcode	Product Code	<i>Product Code (if inputted)</i>
Product Description		<i>Product Description (if inputted)</i>
Hold.W	2.998kg	<i>Weight Held</i>
Total	2.998kg	<i>Total Accumulated Weight</i>

Appendix E: - Customizing Lab 2 Print Format

Various variants + 2 commands (**Cr LF** and **End**) are available for custom print output. Refer to the below **Print output format variants table** for more details.

E.1 Print Output Format Variants Table

Variant	Description	Output Sample
End	End of Input	Not Visible
Cr LF	Hex Code 0D 0A	Not Visible
dAtE	Date of Output	Date 2025-06-25
tiME	Time of Output	Time 17:24:04
nEt	Net Weight	Net 15.000kg
tArE	Tare Weight	Tare 0.000kg
GroSS	Gross Weight	Gross 15.000kg
H rEF	Hi Limit	High 6.000kg
L rEF	Lo Limit	Low 2.000kg
Ani	Weight Hold (Animal Weighing)	Hold.W 0.000kg
Ch rES	Comparison Result	Result Above
trAnS	No. of accumulated transaction	Seq 2
ACC	Total Accumulated Weight	Total_WT 20.000kg
SiGn	Signature Line	
P Code	Product Code	Pcode G3
P dESC	Product Description	Super Scale
Id	Machine ID	Mac 11
GrouP	Machine Group Number	MacGp 22
oPCodE	Operator Number	Opr 8888
C CodE	Customer Code	Name FM
C dESC	Product Description	Fidelity Measurement
Week	Week value and Year	Weeks 1320
t_GS	Accumulated Gross Weight	Total_GS 20.000kg
t_tArE	Accumulated Tare Weight	Total_TA 0.000kg
Expiry	Expiry Duration	Expiry 2025-06-25
Note	Short Note	8899
Abnr	Last Alibi Record Number Saved. <i>Do not use this parameter if Alibi memory function is not activated</i>	12567

E.2 To Edit Custom Lab 2 Print Output Format

Follow the below steps to create a customized printout.

1. Depends on the working modes: -
 - Go to F21 to edit custom output for Weighing mode. Maximum 30 variants can be inputted.
 - Go to F24 to edit custom output for Animal Weighing mode. Maximum 12 variants can be inputted.
2. Press **[Set]**, then **[Unit]** until **Custom** appears.
3. Press **[Set]**,
4. This instrument displays **Line 1** and the last variant or command (refer to **Appendix E.1** for more information) stored,
5. Press **[Set]** to confirm or select other variant or command by pressing **[Func]** or **[Unit]**. Press **[Set]** to confirm and save,
6. This instrument displays **Line 2** and the last variant or command stored,
7. Repeat steps **4** and **5** for other lines,
8. To finish editing, select **End** and press **[Set]** to confirm,
9. This instrument returns to and displays the current internal function number.

At this point, customized Lab2 output format editing is completed.

Appendix F: - Lab 3 Output Format

See below tables for print format illustrations and explanations.

Function & Output	Weighing	Animal
Data 1	Operator Number	
Data 2	Accumulate Sequence No	
Data 3	0	4
Data 4	Machine ID	
Data 5	Machine Group	
Data 6	Date of Output	
Data 7	Time of Output	
Data 8	Customer Code	
Data 9	Product Code	
Data 10	Gross Weight	
Data 11	Tare Weight	
Data 12	Net Weight	
Data 13	Lo Limit (if inputted)	Total Accumulated Net Weight
Data 14	Hi Limit (if inputted)	Weight Unit
Data 15	Check Result	CR (Hex code 0D)
Data 16	Total Accumulated Net Weight	LF (Hex Code 0A)
Data 17	Weight Unit	
Data 18	CR (Hex code 0D)	
Data 19	LF (Hex Code 0A)	

Note: - Semicolon is inserted between data.

Appendix G: - Lab 4 Output Format

See below tables for print format illustrations and explanations.

Weighing Mode	Animal Weighing Mode	Explanation
Name FM	Name FM	<i>Customer Code (if inputted)</i>
Pcode G3	Pcode G3	<i>Product Code (if inputted)</i>
Opr 8888	Opr 8888	<i>Operator No (if inputted)</i>
Mac 11	Mac 11	<i>Machine ID (if inputted)</i>
MacGp 22	MacGp 22	<i>Machine Group No. (if inputted)</i>
Date 2025-06-25	Date 2025-06-25	<i>Date of Output</i>
Time 16:13:40	Time 15:55:27	<i>Time of Output</i>
Seq Gross Net	Seq Gross Net	
001 5.000 5.000 kg	001 5.000 5.000 kg	
002 10.000 10.000 kg	002 10.000 10.000 kg	
003 15.000 15.000 kg	003 15.000 15.000 kg	
004 20.000 20.000 kg	004 19.998 19.998 kg	
-----	-----	
004 50.000 kg	004 49.998 kg	<i>Total Accumulation No., No. of pieces and net weight</i>
Max 20.000 kg	Max 19.998 kg	<i>Maximum Value</i>
Min 5.000 kg	Min 5.000 kg	<i>Minimum Value</i>
Diff 15.000 kg	Diff 14.998 kg	<i>Differentiation (Max-Min)</i>
x 12.5000 kg	x 12.4995 kg	<i>Mean (Average) Value</i>
Sd 6.4550 kg	Sd 6.4542 kg	<i>Standard Deviation</i>
Srel 51.6400 %	Srel 51.6357 %	<i>Relative Standard Deviation</i>
-----	-----	

Appendix H: - Lab 5 Output Format

See below tables for print format illustrations and explanations.

Weighing	Animal Weighing	Explanation
Name FM	Name FM	<i>Customer Code (if inputted)</i>
Pcode G3	Pcode G3	<i>Product Code (if inputted)</i>
Opr 8888	Opr 8888	<i>Operator No (if inputted)</i>
Mac 11	Mac 11	<i>Machine ID (if inputted)</i>
MacGp 22	MacGp 22	<i>Machine Group No. (if inputted)</i>
Date 2025-06-25	Date 2025-06-25	<i>Date of Output</i>
Seq Time Net	Seq Time Net	
001 16:48:24 5.000 kg	001 16:50:54 5.000 kg	
002 16:48:28 10.000 kg	002 16:51:03 10.000 kg	<i>Accumulation No., Time of</i>
003 16:48:31 15.000 kg	003 16:51:12 15.000 kg	<i>Output, Gross or No. of pieces</i>
004 16:48:36 19.990 kg	004 16:51:22 20.000 kg	<i>& Net Weight</i>
-----	-----	
004 Total: 49.990 kg	004 Total: 50.000 kg	<i>Total Accumulation No., No. of</i>
		<i>pieces and net weight</i>
Max 19.990 kg	Max 20.000 kg	<i>Maximum Value</i>
Min 5.000 kg	Min 5.000 kg	<i>Minimum Value</i>
Diff 14.990 kg	Diff 15.000 kg	<i>Differentiation (Max-Min)</i>
x 12.4975 kg	x 12.5000 kg	<i>Mean (Average) Value</i>
Sd 6.4511 kg	Sd 6.4550 kg	<i>Standard Deviation</i>
Srel 51.6191 %	Srel 51.6400 %	<i>Relative Standard Deviation</i>
-----	-----	

Appendix I: - TSC Printer Installation, Setup & Label Upload Procedures

I.1 Get the below ready before Printer Installation

1. An appropriate cable to connect printer and computer. This cable usually comes with the printer. If not, contact your printer supplier.
2. Printer installation driver. This driver usually comes with the printer. If not, contact your printer supplier.
3. Diagnostic tool for the printer. This tool usually comes with the printer. If not, contact your printer supplier or download it at –
https://www.fm.com.tw/files/1/Drivers%20&%20Softwares/DiagTool_V163.zip
4. TCF file for the label printer. The suitable TCF file can be downloaded at: -
www.fm.com.tw/resource/driversnsoftwares



I.2 Printer Installation

1. Turn off the printer, connect the appropriate cable, and then turn on the printer.
2. If the printer supports Plug-and-Play and is connected, the Windows Add Hardware Wizard will detect the printer and display a dialog for driver installation. Click Cancel and do not install the driver using this wizard.
3. Run the Driver Wizard utility from the Installation Directory where the driver files are located.
4. Select Install Printer Drivers and complete the wizard.
5. The driver is now installed.

I.3 Uploading TCF File to Printer

To allow proper operation between instrument and the TSC label printer, a TCF file must be uploaded to the printer.

1. Connect the printer with the computer.
2. Power on the printer.
3. Download the correct TCF file step 4 of I.1.
4. Unzip the download file and save it to the computer.
5. Run Diagnostic tool for the printer.
6. Click on Command Tool.
7. Click on Send File.
8. Double click on the TCF file, and it will be uploaded to the printer.



I.4 Create & Upload Label to TSC Printer





I.4.1 Selecting the Correct Edition for Bartender Software

1. To enable label uploading from computer to TSC printer, it is necessary to run Bartender as Automation or Enterprise Automation edition. Procedures as below: -
2. Install Bartender Software to the computer. The Bartender software usually comes with the TSC printer. If not, please contact your printer supplier.
3. Run Bartender, then click on Help, then click on Edition Selection.
4. Select Enterprise Automation or Automation, then click OK.
5. At this point, the correct Bartender edition is selected.



I.4.2 Adding Information from Instrument to Label & Uploading to a TSC Printer

The below procedures are based on Bartender Label Software. If a different label creating software is used, contact your label software dealer for more details if in doubt.

1. Set the label printer as the default printer of your computer.
2. Create the foundation of a label by Bartender. All information to be obtained from instrument should be added afterward.
3. Once the label foundation has been completed, (a) click on File and (b) select Export Printer Code Template.
4. On Print System, (a) select TSC KP-100/200 (Flash) and (b) select to Port.
5. Click More Option.
6. Then (a) click Print Dialog Data Sources, then (b) click on Format ID/Name.
7. On Template Field, select Template Field for Type.
8. Input the correct label file name on Name/Value. Refer to **paragraph 15.1** for the valid file name format. (a) Click Copies, check KDU, and (b) input asterisk (*) on Prompt box.



9. Below procedures explain how to edit information to be obtained from instrument.
10. Click Template Object Data Sources and select the object which information from instrument (net, gross, tare weight, and product code) to be sent and printed on the label.
11. Double click on the preferred data source to which variant(s) has/have to add.
12. Check the box below External Keyboard, then
13. input the appropriate command on the Prompt Box (refer to Appendix K.1 for command detail).
14. Select Auto on the Source box under Template Field.
15. Repeat steps 11 to 12 for all other data sources.
16. Click OK.
17. Click Export. Verification Messages appear. Select one of the methods on the dialogue box to fix and click Continue.



Appendix J: - Sbarco Printer Installation, Setup & Label Upload Procedures

J.1 Get the below ready before Printer Installation

1. An appropriate cable to connect printer and computer. This cable usually comes with the printer. If not, contact your printer supplier.
2. A serial cable to connect printer and this instrument. Pin #9 of this cable must be without any connection.
3. Download BarDrawer software at <http://www.sbarcotech.com/cht/download.php?gid=1>

J.2 BarDrawer Software & Printer Driver Installation

1. Turn off the printer, connect the computer and printer by cable, and turn on the printer.
2. Install BarDrawer software according to the wizard. After that, BarDrawer software installation is done.
3. Run BarDrawer software.
4. Click Install Driver under Tools (figure 1 below). Then install printer driver according to the wizard.
5. After printer driver installation, click Printer Utility under Tools (figure 2 below).
6. Click Load from Printer (figure 3 below).
7. Check FW version: -
 - If FW version = 3.0.05 (date = 2020/12/18) or newer, printer installation is done.
 - If FW version is lower than 3.0.05 (date = 2020/12/18), then FW update is necessary. Continue with the below step for FW update.
8. Download the latest Sbarco Printer FW at <https://www.fm.com.tw/resource/driversnsoftwares>
9. Open file located of the Sbarco printer FW downloaded.
10. Double click on the FW file name to start Firmware Tool.
11. Click Program (figure 4 below) to start FW update.
12. Click OK after FW update is completed.



Figure 1




Figure 2




Figure 3




Figure 4





Figure 5

J.3 Create & Upload Label to Sbarco Printer

1. Run BarDrawer. Click File and then New.
2. On Printer Driver Selection page: -
 - a. click on the preferred printer driver, then
 - b. select Make Form under Type, then
 - c. click Finished.



3. Double click in the blank label area, then complete all settings on Page, Label Layout, Measurements, and Orientation. Then click OK
4. Create all fixed content and variables on the label.
5. To program variables, double click on the variable to program. On Content page: -
 - a. on Sub-String section, select RS-232 Input for Source and give a proper name to the select variable (optional)
 - b. on Type section, select Single Variable,
 - c. on Format section, input value of Maximum number of characters. Refer to **Appendix K.1 Suggested Length** column for suggested value.
 - d. on Input Data section, select After send instructions (Hex). Then input the Prompt Command listed on K.1.
 - e. Always select 0D,0A for Newline symbol (Hex) box.
 - f. Click OK to save the above settings for this variable.
 - g. Repeat above a ~ f for all other variables.
6. Once the label foundation has been completed, then click on File, then click on Print. On Download Form page: -
 - a. select name of Print to output,
 - b. click Modify and then give a proper name to the file (e.g., AA01... AA99 for an individual transaction label and BB01...BB99 for a totalized label).
 - c. always leave Print with Page Quantity box unchecked.
 - d. set all boxes under Device Settings,
 - e. set of boxes under Media Settings
 - f. Click Download.
7. On Save Form page: -
 - a. make sure that the Form name is correct, then
 - b. Click Save
8. On Select Store Media page: -
 - a. select Printer, then
 - b. select Printer's Flash ROM, then
 - c. click OK

Appendix K: - Label Programming, Illustration & Samples

Prompt commands, information description, working mode and suggested length on the label are listed in the below table.



K.1 Label Prompt Command Table

Prompt Command		Description	Suggested Length
Sbarco	LP50 & TSC		
4B	DATE	Date	10
4C	TIME	Time	8
45	EXPY	Expiry Date	10
46	WEEK	Week	6
66	OPER	Operator No.	4
64	MCID	Machine ID	2
65	MCGP	Machine Group	2
5A	CCDE	Customer Code	18
43	CCDD	Customer Code Description	30
62	PCDE	Product Code	18
44	PCDD	Product Code Description	30
53	CHKL	Low Limit	11
73	chkl	Low Limit in 6-digit integer	6
52	CHKH	High Limit	11
72	chkh	High Limit in 6-digit integer	6
54	CHKR	Check Result	11
51	CWGS	Current Gross Weight	10
71	cwgs	Current Gross Weight in 6-digit integer	6
50	CWTA	Current Tare Weight	10
70	cwta	Current Tare Weight in 6-digit integer	6
4F	CWNT	Current Net Weight	10
6F	cwnt	Current Net Weight in 6-digit integer	6
59	CWNT	Current Animal Weight	11
79	cwnt	Current Animal Weight in 6-digit integer	6


4D	ASEQ	Accumulation Sequence No.	8
6D	aseq	Accumulation Sequence No. in 6-digit integer	6
47	AWGS	Accumulated Gross Weight	11
67	awgs	Accumulated Gross Weight in 6-digit integer	6
4A	AWTA	Accumulated Tare Weight	11
6A	awta	Accumulated Tare Weight in 6-digit integer	6
4E	AWNT	Accumulated Net Weight	11
6E	awnt	Accumulated Net Weight in 6-digit integer	6
4E	AWNT	Accumulated Animal Weight	11
6E	awnt	Accumulated Animal Weight in 6-digit integer	6
68	ABNR	Last Alibi Record Number Saved <i>Do not use this parameter if Alibi memory function is not activated.</i>	8

K.2 Label programming Illustration

K.2.1 Label Illustration for LP50 & TSC



K.2.2 Label Illustration for Sbarco



K.3 Sample Labels

Label files of the above samples (size = 50 x 80mm) with prompt commands are available for download at: - <https://www.fm.com.tw/resource/driversnsoftwares>


Appendix L: - Keyboard Commands²¹

Keyboard commands can be sent to this instrument from a computer through any standard communication program to simulate keyboard entries. Keyboard command format as below: -

- Start String * "asterisk" (Hex code 02A), followed by
- Letters KB, followed by
- The letter shown on the below illustration diagram (keyboard commands are case sensitive), followed by
- End String # "number sign" (Hex code 23).

Example to send manual Zero key command to instrument, input *KBA#

Keyboard Command Illustration Diagram



²¹ Keyboard commands are case sensitive.

Appendix M: - System Execution Commands

System execution command format as below: -

- a. Start String * “asterisk” (Hex code 02A), followed by
- b. Command code as shown on below table (all commands are case sensitive), followed by
- c. End String # “number sign” (Hex code 23).

Command Definition	Command Format			
	Start String	Command Code		End String
System Reboot	*	EX	F000	#
All Segment Check	*	EX	F002	#
System (F7~F37) Initialization	*	EX	F006	#
Reset WIFI Module to Default Setting	*	EX	F048	#
Reset Bluetooth Module (BT 2.0 only)	*	EX	F053	#
Reload Factory Settings to BT Module (BT 2.0 only)	*	EX	F054	#
Save changes and restart	*	EX	F999	#

Appendix N.1: - Management Report Execution Commands

Management report execution command format as below: -

- Start String * "asterisk" (Hex code 02A), followed by
- Command code as shown on below table (all commands are case sensitive), followed by
- End String # "number sign" (Hex code 23).

Command Definition	Command Format				Parameter Description
	Start String	Command Code		Parameter & End String	
Output all data in Alibi memory.	*	EX	RPTA	;d1;d2;d3;d4;d5#	Search Criteria - d1 = Operator number 0000~9999. Blank = all. - d2 = C Code. 1~18 digit Customer Code. Blank = all. - d3 = P Code. 1~18 digit Product Code. Blank = all. - d4 = Check Result. Lo = Below; OK = Accept; Hi = Above; NG = Lo or HI. Blank = all. - d5 = Transaction Note to Alibi Memory.
Output data of today in Alibi memory.	*	EX	RPTD	;d1;d2;d3;d4;d5#	
Output data of current month in Alibi memory.	*	EX	RPTM	;d1;d2;d3;d4;d5#	
Output data for a specific period in Alibi memory.	*	EX	RPTP	;d1;d2;d3;d4;d5;d6;d7#	Search Criteria - d1 = Data starting date. 6 digit according F4 setting. - d2 = Data ending date. 6 digit according F4 setting - d3 = Operator number 0000~9999. Blank = all. - d4 = C Code. 1~18 digit Customer Code. Blank = all. - d5 = P Code. 1~18 digit Product Code. Blank = all. - d6 = Check Result. Lo = Below; OK = Accept; Hi = Above; NG = Lo or HI. Blank = all. - d7 = Transaction Note to Alibi Memory.
Output data for a specific system sequence range in Alibi memory. See Appendix N.2	*	EX	RPTR	;d1;d2#	- d1 = Starting number of the system sequence (range: 0 to 131071). - d2 = Ending number of the system sequence (range: 0 to 131071). Note: The search criteria function is disabled under this command. All content within the data range will be outputted.
Output the last data in Alibi memory. See Appendix N.2	*	EX	RPTL	#	Note: The search criteria function is disabled under this command. All content within the data range will be outputted.

Appendix N.2: - Relationship between ABSN (Alibi Memory Address Number) and ABNR (Alibi Record Number)

N.2.1 About Alibi Memory Address Number (ABSN)

- ABSN is the actual physical address of a transaction record in the Alibi memory.
- The ABSN ranges from 0 to 131,071. After reaching 131,071, it resets to 0 and starts counting again.

N.2.2 About Alibi Record Number (ABNR)

- ABNR is a unique number assigned to a transaction record.
- The ABNR ranges from 0 to 99,999,999. After reaching 99,999,999, it resets to 0 and begins counting again.

N.2.3 Cycle Relationship:

Assuming both the ABSN and ABNR start at 0, when the ABNR surpasses 131,071, it indicates that the Alibi Memory Address Number (ABSN) has completed one full cycle. Each additional cycle of the ABSN is represented by a corresponding increase in the ABNR value beyond 131,071.

N.2.4 Example Scenario

Assuming both the ABSN and ABNR start at 0:

- From 0 to 131,071, the values of ABSN and ABNR are identical.
- After 131,071, the ABSN resets to 0, but the ABNR continues to increase. This means that from this point forward, the ABNR will always be higher than the ABSN.

Detailed Example

- Assume both the ABSN and ABNR start from 0.
- When ABNR is 800,000:
 1. Each complete cycle of ABSN is 131,072 (0 to 131,071).
 2. Determine how many full cycles have been completed:
 - Divide ABNR by the cycle length of ABSN: $800,000 / 131,072 = 6$ full cycles, with a remainder.
 3. Calculate the remainder to find the current ABSN value:
 - $800,000 - (6 \times 131,072) = 800,000 - 786,432 = 13,568$.

Result:

- When ABNR = 800,000, the corresponding ABSN = 13,568.
- This indicates that the ABSN has completed 6 full cycles and is currently at 13,568 in the 7th cycle.

Appendix O: - System Parameter & Operation Entry Setting Commands

System parameter & operation entry setting command format as below: -

- Start String * "asterisk" (Hex code 02A), followed by
- Command code as shown on below table (all commands are case sensitive), followed by
- Parameter(s) listed on the below table. Always insert semicolon (;) in front of each parameter, followed by
- End String # "number sign" (Hex code 23).

Command Description Table

Command Definition	Command Format			Parameter Description
	Start String	Command Code	Parameter & End String	
Set Date Format, Value and Output	*	ST	F004	;d1;d2;d3# - d1 = Date Format (0 = DD-MM-YY, 1 = YY-MM-DD, 2 = MM-DD-YY) - d2 = 8-digit date value as per above setting (AA-BB-CC) - d3 = Date Output Format (0 = Normal Format, 1 = Week Format)
Set Time	*	ST	F005	;d1# 8-digit time value (HH:MM:SS)
Set Auto Power Off	*	ST	F007	;d1# 0 = Off, 1 = 1 minute, 2 = 3 minute, 3 = 5 minute 4 = 10 minute, 5 = 20 minute, HH:MM:SS = exact power off time
Set Brightness and Color Ratio	*	ST	F008	;d1;d2# - d1 = Brightness (01~99) - d2 = Color Ratio (01~99)
Set Filter Strength & AD Conversion Speed	*	ST	F010	;d1;d2;d3# - d1 = Filter (1~9 for Filter 1~9) - d2 = Anti-vibration levels (1 ~ 5) - d3 = AD Conversion Speed (015/030/060/120)
Set Auto Tare Function	*	ST	F012	;d1# - M = Off, - A = Auto, 00 ~ 99 = Continuous tare (in term of 1/10 second)
Set Repetitive Tare Function	*	ST	F013	;d1# 0 = Off, 1 = On
Set Buzzer	*	ST	F014	;d1;d2;d3# - d1 = Keyboard Buzzer (0 = Off, 1 = On) - d2 = System Buzzer (0 = Off, 1 = On) - d3 = Non-Resettable Memory Buzzer (0 = Off, 1 = On)
Set Result Buzzer & Action on Negative Value	*	ST	F015	;d1;d2# - d1 = Check Buzzer (0 = Off, 1 = IN, 2 = Out, 3 = Hi, 4 = Lo) - d2 = Action on Negative Value (0 = Off, 1 = On)
Set Keyboard Lock	*	ST	F020	;d1# 0 = Off, 1 = On

Set Near Zero Value	*	ST	F026	;d1#	Maximum 8 digits including decimal (if any)
Set Ask for Operator Number when Power On	*	ST	F028	;d1#	0 = No, 1 = Yes
Set Allow Letters and Symbols for Customer & Product Code Manual Entry	*	ST	F030	;d1#	0 = No, 1 = Yes
Set Report Output Comport	*	ST	F033	;d1#	0 = UART 0; 1 = UART 1; 2 = Bluetooth; 3 = WIFI; 4 = USB-C
Set Customer Code and Description	*	ST	CCDE	;d1;d2#	d1 = 1~18-digit Customer Code. Blank = nothing d2 = 1~30 Customer Code Description. Blank = nothing
Set Product Code and Description	*	ST	PCDE	;d1;d2#	- d1 = 1~18-digit Product Code. Blank = nothing - d2 = 1~30 Product Code Description. Blank = nothing
Set Weight Check Limits	*	ST	CHKW	;d1;d2#	- d1 = Lo limit (Maximum 8 digit including decimal, if any). Blank = nothing - d2 = Hi limit (Maximum 8 digit including decimal, if any). Blank = nothing
Set Pre-set Tare Value (Note O1)	*	ST	PSTA	;d1#	Maximum 8 digit including decimal
Set @WT	*	ST	AVGW	;d1#	Maximum 8 digit including decimal
Set Expiry Duration	*	ST	EXPY	;d1#	4 digits. 0000 = today, 9999 = 9999 days plus today

Note O1: - If old preset tare value already exists in memory, 2 command strings are necessary: -

- a. 1st command string to clear this old preset tare value first.
- b. 2nd command string to set new preset tare value.

Appendix P.1: - System Parameter & Operation Entry Reading Commands

Operation entry reading command format as below: -

- Start String * "asterisk" (Hex code 02A), followed by
- Command code as shown on below table (all commands are case sensitive), followed by
- End String # "number sign" (Hex code 23).

Command Description Table

Command Definition	Command Format				Parameter Output	Parameter Description
	Start String	Command Code		End String		
Read Internal AD value	*	RD	F001	#	d1	8 digit AD value
Read Capacity, Division & Default Weight Unit	*	RD	F003	#	d1;d2	d1 = Capacity x Division of W1 d2 = Capacity x Division of W2 (if set)
Read Date Format, Value and Output Settings	*	RD	F004	#	d1;d2;d3	d1 = Date Format (0 = DD-MM-YY, 1 = YY-MM-DD, 3 = MM-DD-YY) d2 = 8-digit date value as per above setting (AA-BB-CC) d3 = Date Output Format (0 = Normal Format, 1 = Week Format)
Read Time	*	RD	F005	#	d1	8-digit time value (HH:MM:SS)
Read Auto Power Off	*	RD	F007	#	d1	0 = Off 1 = 1 minute 2 = 3 minute 3 = 5 minute 4 = 10 minute 5 = 20 minute HH:MM:SS = exact power off time
Read Brightness and Color Ratio	*	RD	F008	#	d1;d2	d1 = Brightness (01~99) d2 = Color Ratio (01~99)
Weight Unit Employed	*	RD	F009	#	d1;d2;d3	d1 = kg: - 0 = Off; 1 = On d2 = g: - 0 = Off; 1 = On d3 = lb: - 0 = Off; 1 = On
Read Filter Strength & AD Conversion Speed	*	RD	F010	#	;d1;d2;d3#	- d1= Filter (1~9 for Filter 1~9) - d2 = Anti-vibration levels (1 ~ 5) - d3 = AD Conversion Speed (015/030/060/120)
Read Auto Tare Function	*	RD	F012	#	d1	M = Off, A = Auto, 00 ~ 99 = Continuous tare (in term of 1/10 second)

Read Repetitive Tare Function	*	RD	F013	#	d1	0 = Off, 1 = On
Read Buzzer	*	RD	F014	#	d1;d2;d3	d1 = Keyboard Buzzer (0 = Off, 1 = On) d2 = System Buzzer (0 = Off, 1 = On) d3 = Non Resettable Memory Buzzer (0 = Off, 1 = On)
Read Result Buzzer & Action on Negative Value	*	RD	F015	#	d1;d2	d1 = Check Buzzer (0 = Off, 1 = IN, 2 = Out, 3 = Hi, 4 = Lo) d2 = System Buzzer (0 = Off, 1 = On)
Read Keyboard Lock	*	RD	F020	#	d1	0 = Off, 1 = On
Set Near Zero Value	*	RD	F026	#	d1	Maximum 8 digits including decimal (if any)
Read Ask for Operator Number when Power On	*	RD	F028	#	d1	0 = No, 1 = Yes
Read Calibration & Parameter Counts and Pointer Value	*	RD	F029	#	d1;d2;d3	d1= Calibration Count d2 = Parameter Set Count d3 = Pointer Value
Read Allow Letters and Symbols for Customer & Product Code Manual Entry	*	RD	F030	#	d1	0 = No, 1 = Yes
Read Report Output Comport	*	RD	F033	#	d1	0 = UART 0; 1 = UART 1; 2 = Bluetooth; 3 = WIFI; 4 = USB-C
Read Customer Code	*	RD	CCDE	#	d1	Maximum 18 digits
Read Customer Code Description	*	RD	CCDD	#	d1	Maximum 30 digits
Read Product Code	*	RD	PCDE	#	d1	Maximum 18 digits
Read Product Code Description	*	RD	PCDD	#	d1	Maximum 30 digits
Read Machine ID	*	RD	MCID	#	d1	2-digit
Read Machine Group	*	RD	MCGP	#	d1	2-digit
Read Operator No.	*	RD	OPER	#	d1	4-digit
Read Date	*	RD	DATE	#	d1	8-digit
Read Expiry Date	*	RD	EXPY	#	d1	8-digit

Read Time	*	RD	TIME	#	d1	8-digit
Read Week	*	RD	WEEK	#	d1	6-digit
Read Last Alibi Record Number (ABNR) Saved <i>Do not use this parameter if Alibi memory function is not activated.</i>		RD	ABNR	#	d1	8-digit

Appendix P.2: - Parameter Reading Commands of Production Settings PLU in effect

Operation entry reading command format as below: -

- Start String * "asterisk" (Hex code 02A), followed by
- Command code as shown on below table (all commands are case sensitive), followed by
- End String # "number sign" (Hex code 23).

Command Description Table

Command Definition	Command Format			Parameter Output	Parameter Description	
	Start String	Command Code	End String			
Read Date Output Format	*	RDA	004	#	d1	Date Output Format (0 = Normal Format; 1 = Week Format)
Read Auto Tare Function	*	RDA	012	#	d1	M = Off; A = Auto; 00 ~ 99 = Continuous tare (in term of 1/10 second)
Read Expiry Duration	*	RDA	036	#	d1	4-digit (0 ~ 9999) in terms of day

Appendix Q: - Operation Result Reading Commands

Operation result reading command format as below: -

- Start String * "asterisk" (Hex code 02A), followed by
- Command code as shown on below table (all commands are case sensitive), followed by
- End String # "number sign" (Hex code 23).

Command Description Table

Command Definition	Command Format				Parameter Output	Parameter Description
	Start String	Command Code	End String			
Read Current Tare Weight	*	RD	CWTA	#	d1	8-digit including decimal
Read Current Gross Weight	*	RD	CWGS	#	d1	8-digit including decimal (if any)
Read Current Net Weight	*	RD	CWNT	#	d1	8-digit including decimal (if any)
Read Weight Unit of Current Net, Tare and Gross Weight	*	RD	CWUN	#	d1	8-digit including decimal (if any)
Read Low Limit	*	RD	CHKL	#	d1	8-digit including decimal (if any)
Read High Limit	*	RD	CHKH	#	d1	8-digit including decimal (if any)
Read Check Target	*	RD	CHKT	#	d1	kg = kilogram, (space)g = gram,
Read Check Result	*	RD	CHKR	#	d1	Below/Accept/Above
Read Accumulated Gross Weight	*	RD	AWGS	#	d1	8-digit including decimal (if any)
Read Accumulated Tare Weight	*	RD	AWTA	#	d1	8-digit including decimal (if any)
Read Accumulated Net Weight	*	RD	AWNT	#	d1	8-digit including decimal (if any)
Read Weight Unit of Accumulated Net, Tare and Gross Weight	*	RD	AWUN	#	d1	8-digit including decimal (if any)
Read Accumulation sequence No.	*	RD	ASEQ	#	d1	6-digit
Read Current Tare Weight in 6-digit format and without decimal	*	RD	cwta6	#	d1	6-digit
Read Current Gross Weight in 6-digit format and without decimal	*	RD	cwgs6	#	d1	6-digit
Read Current Net Weight in 6-digit format and without decimal	*	RD	cwnt6	#	d1	6-digit

Read Low Limit in 6-digit format and without decimal	*	RD	chkl6	#	d1	6-digit
Read High Limit in 6-digit format and without decimal	*	RD	chkh6	#	d1	6-digit
Read Accumulated Gross Weight in 6-digit format and without decimal	*	RD	awgs6	#	d1	6-digit
Read Accumulated Tare Weight in 6-digit format and without decimal	*	RD	awta6	#	d1	6-digit
Read Accumulated Net Weight in 6-digit format and without decimal	*	RD	awnt6	#	d1	6-digit
Read Accumulation sequence No	*	RD	aseq6	#	d1	6-digit

Appendix R: - Production Settings PLU Saving Commands

Production Settings PLU saving commands format as below: -

- Start String * "asterisk" (Hex code 02A), followed by
- Command code as shown on below table (all commands are case sensitive), followed by
- Parameters listed on the below table. Always insert semicolon (;) in front of each parameter, followed by
- End String # "number sign" (Hex code 23).

R.1 Command Description Table

Start String	Command Code (Note R1)	Parameter	End String
*	S1 or S2 or S3	LP ;d1;d2;d3;d4;d5;d6;d7;d8;d9;d10;d11;d12;d13;d14;d15	#

Note R1: -

- S1 = command for operation with weight unit = kg.
- S2 = command for operation with weight unit = g.
- S3 = command for operation with weight unit = lb.

R.2 Parameter Description Table

Parameter #	Description	Parameter
d1	PLU #	01 ~ 99
d2	Customer Code	1~18-digit (; * # not accepted). Blank = Nothing
d3	Customer Description	Maximum 30 characteristics (; * # not accepted). Blank = Nothing
d4	Product Code	1~18-digit (; * # not accepted). Blank = Nothing
d5	Product Description	Maximum 30 characteristics (; * # not accepted). Blank = Nothing
d6	Low Check limit	Maximum 8 digits, including decimal. Blank = Nothing
d7	Reserved	Always input 0 here
d8	Hi Check limit	Maximum 8 digits, including decimal. Blank = Nothing
d9	Check Target	W = Weight Blank = Weight

Parameter #	Description	Parameter
d10	Auto Tare Type	M = Manual tare A = auto tare 00 ~ 99 = Continuous tare in term of 1/10 second Blank = current instrument setting.
d11	Preset Tare Value	Maximum 8 digits, including decimal. Blank = Nothing
d12	Date Format	0 = Normal 1 = Week
d13	Expiry Duration	Maximum 4 digits (0 ~ 9999) 0 or blank = F4 value 1 ~ 9999 = No. of day plus F4 value
d14	Individual Label File Number to Print FL1 (Label Format Group 1)	00 ~ 99 00 = No label file output
d15	Totalized Label File Number to Print FL2 (Label Format Group 2)	00 ~ 99 00 = No label file output

Appendix S: Production Settings PLU Reading Commands

Production Settings PLU reading commands format as below: -

- Start String * "asterisk" (Hex code 02A), then followed by
- Command string listed on below table, then followed by
- Parameters listed on the below table. Always insert semicolon (;) in front of each parameter, followed by
- End String # "number sign" (Hex code 23).

S.1 Command Description Table

Start String	Command Code (Note S1)	Parameter & End String	Parameter Output
*	R1 or R2 or R3	LP ;1~99 or ;A (1~99 = No. of the PLU number. A = all)	d1;d2;d3... ;d16

Remark: If parameter A is inputted, instrument sends content of PLU 01 to PLU 99 in numeric sequence.

Note S1: -

- R1 = command to read content from Production Settings PLU of weight unit kg.
- R2 = command to read content from Production Settings PLU of weight unit g.
- R3 = command to read content from Production Settings PLU of weight unit lb.

Refer to below table for content of output. A semicolon is inserted between parameters.

S.2 Parameter Output Description Table

Parameter #	Parameter Output	Parameter Description
d1	Weight Unit Code	U1 = kg U2 = g U3 = lb
d2	PLU #	01 ~ 99
d3	Customer Code	1~18-digit (* and # not accepted) Blank = Nothing
d4	Customer Description	Maximum 30 characteristics (; * # not accepted). Blank = Nothing
d5	Product Code	1~18-digit (* and # not accepted) Blank = Nothing
d6	Product Description	Maximum 30 characteristics (; * # not accepted). Blank = Nothing
d7	Reserved Data	Always = 0

d8	Low Check limit	Maximum 8 digits, including decimal. Blank = Nothing
d9	Hi Check limit	Maximum 8 digits, including decimal. Blank = Nothing
d10	Check Target	W = Weight
d11	Auto Tare Type	M = Manual; A = Auto Tare; 00~99 = Delay time of Continuous Tare
d12	Preset Tare Value	Maximum 8 digits, including decimal. Blank = Nothing
d13	Date Format	0 = Normal; 1 = Week
d14	Expiry Duration	Maximum 4 digits (0 ~ 9999) 0 = F4 value; 1 ~ 9999 = No. of day plus F4 value
d15	Individual Label File Number to Print FL1 (Label Format Group 1)	00 ~ 99 00 = No label file output
d16	Totalized Label File Number to Print FL2 (Label Format Group 2)	00 ~ 99 00 = No label file output

Appendix T: Production Settings PLU Execution Commands

Production Settings PLU execution command format as below: -

- a. Start String * “asterisk” (Hex code 02A), then followed by
- b. Command string listed on below table, then followed by
- c. Parameters listed on the below table. Always insert semicolon (;) in front of each parameter, followed by
- d. End String # “number sign” (Hex code 23).

Command Description Table

Start String	Command Code (Note T1)		Parameter	End String
*	E1 or E2 or E3	LP	;1~ 99 (1~99 = No. of the Production Settings PLU number)	#

Note T1: -

- E1 = command to execute Production Settings PLU of weight unit kg.
- E2 = command to execute Production Settings PLU of weight unit g.
- E3 = command to execute Production Settings PLU of weight unit lb.



Fidelity Measurement Company Limited

 www.fm.com.tw

 info@fm.com.tw